



A. SGB9000S whole machines




部件图NO .	序号 NO.	零部件编码 Part No.	Desription
			English
A	1	20130-00110-03	Fuel tank assembly
A	2	20029-12703-00	Alternator assembly
A	3	20090-00866-00	Frame assembly
A	4	20260-06974-00	Engine assembly
A	5	20202-00647-00	Muffler assembly
A	6	20114-06915-00	Control panel assembly

B. fuel tank




部件图NO .	序号 NO.	零部件编码 Part No.	Desription	quantity
			English	
B	1	20131-00014-00	Fuel tank cover	1
B	2	34037-00020-00	Fuel filter	1
B	3	70010-00145-00	Oil leveler	1
B	4	30101-00407-00	Flange bolt	4
B	5	30136-00074-00	Fuel tank washer	4
B	6	34032-00024-00	Bushing	4
B	7	33015-00034-00	Fuel tank rubber mat	4
B	8	20133-00002-00	Fuel valve	1
B	9	34024-00002-00	Clamp	2
B	10	34023-00004-00	Fuel pipe	0.18M

C. alternator



部件图NO .	序号 NO.	零部件编码 Part No.	Desription	quantity
			English	
C	1	20029-12703-00	Alternator assembly	1
C	1-1	20256-02198-00	Rotor	1
C	1-2	20046-07912-00	Stator	1
C	2	30136-00126-00	Plain washer	1
C	3	30101-00113-00	Flange bolt	1
C	4	20183-00015-00	Carbon brush	1
C	5	30101-00068-00	Flange bolt	5
C	6	30101-00066-00	Flange bolt	3
C	7	33082-00290-01	Alternator end cover	1
C	8	20044-00178-00	Voltage regulator	1
C	9	20107-00018-00	Wiring board	1
C	10	33085-00087-00	Alternator bracket	1
C	11	30101-00090-00	Flange bolt	4
C	12	30101-00624-00	Flange bolt	2
C	13	30139-00005-00	Spring Washer	2
C	14	30128-00008-00	Lock nut	2
C	15	30101-00511-00	Flange bolt	4
C	16	33191-00023-00	Motor end cover	1
C	17	20249-00144-00	Supporting member	1
C	18	30101-00041-00	Flange bolt	2
总值				

D. frame




部件图NO .	序号 NO.	零部件编码 Part No.	Desription	quantity
			English	
D	1	33015-00005-00	Handlebar rubber cover	2
D	2	20135-00211-00	Handlebar components	2
D	3	33036-00066-00	Handlebar plastic plug	2
D	4	30101-00465-00	Flange bolt	2
D	5	33275-00023-00	Washer	4
D	6	30125-00003-00	Flange bolt	2
D	7	20014-00154-00	Support	2
D	8	30125-00003-00	Flange nut	8
D	9	30125-00002-00	Flange nut	2
D	10	30101-00042-00	Flange bolt	2
D	11	30101-00356-00	Flange bolt	4
D	12	34030-00104-00	Vibration absorb	4
D	13	/	Vibration absorb	0
D	13-1	/	Vibration absorb	0
D	14	30125-00027-00	Flange nut	4
D	15	20196-00122-00	Ground terminal	1
D	16	34030-00009-00	Vibration absorb	1
D	17	30101-00070-00	Flange bolt	1
D	18	33301-00010-00	Washer	1

D	19	30125-00002-00	Flange nut	1
D	20	34031-00027-00	Axle	2
D	21	30136-00086-00	Flat washer	2
D	22	20134-00024-00	Wheel assembly	2
D	23	34006-00020-00	Clip, dowel pin	2
D	24	20090-00866-00	Frame components	1
D	25	34030-00079-00	Brackets rubber washer	2
D	26	30101-00070-00	Flange bolt	2
D	27	20217-00038-00	Battery board	1
D	28	31002-00046-00	Battery board	1


E.Engine

E-01 .气缸头组件 Cylinder head




部件图 NO.	序号 NO.	零部件编码 Part No.	Desription	quantity
			English	
E-01	1	30101-00071-00	BOLT	4
E-01	2	20021-00018-00	COVER COMP. HEAD	1
E-01	3	33048-00154-00	GASKET, HEAD COVER	1
E-01	4	30101-00070-00	BOLT	5
E-01	5	34021-00014-00	WIND COVER, DOWN	1
E-01	6	34021-00061-02	WIND COVER	1
E-01	7	30101-00289-00	BOLT	4
E-01	8	30110-00027-00	BOLT, STUD, EXHAUST	2
E-01	9	20027-00010-00	SPARK PLUG	1
E-01	10	20023-00049-00	CYLINDER HEAD COMP	1
E-01	11	33048-00036-00	GASKET, HEAD COVER	1
E-01	12	34006-00007-00	DOWEL PIN	2
E-01	13	30110-00021-00	BOLT, STUD, INTAKE	2
E-01	14	34024-00056-00	CLAMP	1
E-01	15	34023-00074-00	TUBE, BREATHER	1


E-02 箱体组件 Crankcase assy



部件图NO.	序号NO.	零部件编码Part No.	Description	quantity
			English	
E-02	1	30101-00342-00	BOLT	2
E-02	2	33247-00027-00	ENGINE OIL SENSOR	1
E-02	3	30141-00112-00	BEARING	1
E-02	4	34007-00002-00	OIL SEAL	1
E-02	5	34006-00017-00	PIN, LOCK	1
E-02	6	30136-00095-00	WASHER	2
E-02	7	34026-00005-01	SHAFT, GOVERNOR	1
E-02	8	34011-00070-02	CRANKCASE	1
E-02	9	20149-00016-00	START MOTOR	1
E-02	10	30101-00461-00	BOLT	2
E-02	11	20009-00027-00	CHARGING COIL	1
E-02	12	33593-00007-00	CRIMPING BOARD	1
E-02	13	30101-00070-00	BOLT	1
E-02	14	30101-00530-00	BOLT	2
E-02	15	34007-00012-00	OIL SEAL	1
E-02	16	30136-00080-00	WASHER	2
E-02	17	30101-00514-00	BOLT	2


E-03 曲轴箱盖Crankcase cover





部件图NO.	序号NO.	零部件编码Part No.	Desription	quantity
			English	
E-03	1	34007-00012-00	OIL SEAL	1
E-03	2	30101-00370-00	BOLT	10
E-03	3	20026-00005-00	DIPSTICK ASSY	1
E-03	4	33129-00019-00	CRANKCASE COVER	1
E-03	5	20013-00004-00	GOVERNOR GEAR KIT	1
E-03	6	30141-00112-00	BEARING	1
E-03	7	30141-00118-00	BEARING	1
E-03	8	33048-00066-00	GASKET, CRANKCASE COVER	1
E-03	9	34006-00001-00	DOWEL PIN	2


E-04曲轴活塞连杆总成 Crankshaft piston



部件图NO.	序号NO.	零部件编码Part No.	Desription	quantity
			English	


E-04	1	20084-00011-00	RING SET, PISTON	1
E-04	2	30150-00023-00	CLIP, PISTON PIN	2
E-04	3	34004-00018-00	PISTON	1
E-04	4	20008-00009-00	CONNECTING ROD ASSY	1
E-04	5	34006-00015-00	PIN, PISTON	1
E-04	6	20011-00063-00	CRANKSHAFT ASSY	1

E-05凸轮轴（配气结构） Camshaft




部件图NO.	序号NO.	零部件编码Part No.	Description	quantity
			English	
E-05	1	33141-00022-00	ROTATOR, VALVE	2
E-05	2	34016-00007-00	RETAINER, VALVE SPRING	2
E-05	3	34015-00023-00	SPRING, VALVE	2
E-05	4	34016-00008-00	RETAINER, VALVE BOTTOM	2
E-05	5	34007-00001-00	OIL SEAL	2
E-05	6	34013-00034-00	VALVE, EXHAUST	1
E-05	7	34013-00080-00	VALVE, INTAKE	1
E-05	8	30212-00034-00	NUT, VALVE ADJUSTING	2
E-05	9	30134-00005-00	ROCKER SHAFT	2
E-05	10	34019-00005-00	ROCKER ARM	2
E-05	11	30110-00109-00	BOLT VALVE	2
E-05	12	34017-00008-00	PLATE, PUSH ROD GUIDE	1
E-05	13	34020-00010-00	PUSH ROD	2
E-05	14	34008-00006-00	LIFTER, VALVE	2
E-05	15	34033-00008-00	BALANCE SHAFT	1
E-05	16	20012-00015-00	CAMSHAFT, ASSY	1


E-06 化油器总成 Carburetor



部件图N O.	序号 NO.	零部件编码 Part No.	Desription	quantity
			English	
E-06	1	33048-00053-00	GASKET, INTAKE	1
E-06	2	34012-00014-00	INSULATOR, CARBURETOR	1
E-06	3	33048-00078-00	GASKET, CARBURETOR	1
E-06	4	20024-00524-00	CARBURETOR	1
E-06	5	33048-00047-00	GASKET, AIR CLEANER	1
E-06	6	34024-00002-00	CLIP, FUEL PIPE	1
E-06	7	34023-00004-00	FUEL PIPE	0.18m
E-06	8	34024-00008-00	WIRE CLIP	2


E-07 反冲起动器总成 Recoil starter






部件图N O.	序号 NO.	零部件编码 Part No.	Desription	quantity
			English	
E-07	1	30101-00070-00	BOLT, M6×12	5
E-07	2	70010-00824-00	WIND GUIDER, RECOIL	1
E-07	3	30101-00337-00	BOLT, FLANGE	3
E-07	4	20034-00030-00	RECOIL STARTER PULLER	1
E-07	5	20010-00106-07	RECOIL STARTER COMP	1

E-08调速控制系统Control




部件图N O.	序号 NO.	零部件编码 Part No.	Desription	quantity
			English	
E-08	1	20022-00018-00	SPEED CONTROL, ASSY	1
E-08	2	30101-00070-00	BOLT	2
E-08	3	34015-00020-00	SPRING, CABLE RETURN	1
E-08	4	34025-00007-00	HANDLE, SPEED CONTROL	1
E-08	5	34015-00010-00	SPRING, THROTTLE RETURN	1
E-08	6	34026-00008-00	ROD, GOVERNOR	1

E-09飞轮Flywheel



部件图NO.	序号NO.	零部件编码Part No.	Desription	quantity
			English	
E-09	1	20028-00029-02	WIRE, ENGINE SWITCH	1
E-09	2	30101-00408-00	BOLT, FLANGE	2
E-09	3	20051-00020-00	FLYWHEEL COMP	1
E-09	4	33155-00042-00	FAN COOLING	1
E-09	5	34022-00028-00	PULLEY, STARTER	1
E-09	6	30125-00064-00	NUT SPECIAL	1
E-09	7	33246-00003-00	OIL ALARM	1
E-09	8	30101-00070-00	BOLT, FLANGE	1


E-10 空气滤清器 Air cleaner






部件图N O.	序号 NO.	零部件编码 Part No.	Desription	
			English	quantity
E-10	1	20025-00083-00	AIR CLEANER ASSY	1

F.muffler



部件图N O.	序号 NO.	零部件编码 Part No.	Desription	quantity
			English	
F	1	20249-00193-00	Support part	1
F	2	30101-00342-00	Flange bolt	2
F	3	30101-00370-00	Flange bolt	1
F	4	30136-00014-00	Washer	1
F	5	30125-00003-00	Flange nut	1
F	6	33048-00093-00	Muffler washer	2
F	7	30139-00037-00	Spring washer	2
F	8	30121-00040-00	Hex nut	2
F	9	20202-00647-00	Muffler	1
F	10	33499-00018-00	Air cleaner support	1
F	11	30125-00002-00	Flange nut	1

G.Control panel



部件图N O.	序号 NO.	零部件编码 Part No.	
G	1	20114-06915-00	
G	2	20114-06915-00001	
G	3	31026-00160-02	
G	4	20270-00004-00	
G	5	20270-00003-00	
G	6	31008-00048-00	
G	7	31037-00104-04	
G	8	31034-00023-00	
G	9	31038-00024-00	
G	10	70009-00396-00	
G	11	31038-00046-00	
G	12	31034-00077-00	