

Index to engineer group

E-01 机芯组件.....2~3

Machine core components

E-03 机架组件.....7~8

Panel assembly


E-02 覆盖件组件.....4~6

Overlay component

E-04 底板组件.....9~10

Base plate assembly


E-01 机芯组件 Machine core components



序号 NO.	零部件编码 Part NO.	零部件名称 Description			数量 QTY		
		中文	English	Price (USD)		SC4000i	N.W. (kg) /PC
1	20260-02556-04	SV230-变频机动力	Engine SV230, invertor generator			1	
2	33138-00018-00	橡胶密封条	Seal, rubber strip			1	
3	33277-00008-00	接线板	Wiring ground			1	
4	33191-00116-00	电机罩	Alternator cover			1	
5	30101-00359-00	六角法兰面螺栓	Flange bolt			4	
6	34006-00001-00	定位销	Locating pin			2	
7	20005-00083-00	变频电机定子	Stator assy, invertor generator			1	
8	30139-00017-00	弹簧垫圈	Spring washer			4	
9	30113-00105-00	内六角圆柱头螺钉	Bolt			4	

10	20006-00026-00	变频电机转子	Rotor assy, invertor generator			1	
11	30125-00011-00	六角法兰面螺母	Flange nut			1	
12	33155-00043-00	风扇	Fan			1	
13	30136-00094-00	平垫圈	Flat washer			3	
14	30139-00034-00	弹簧垫圈	Spring washer			3	
15	30101-00405-00	六角法兰面螺栓	Flange bolt			3	
16	34021-00161-00	电机导风罩	Alternator hood			1	
17	30101-00405-00	六角法兰面螺栓	Flange bolt			4	
18	33014-00603-00	电机后罩	Alternator			1	
19	30101-00329-00	六角法兰面螺栓	Flange bolt			4	
20	34028-00019-00	进气管	Intake pipe			1	
21	33089-00077-00	动力支撑板	Power support plate			1	
22	30101-00369-00	六角法兰面螺栓	Flange bolt			4	
23	33014-00419-00	支撑板	Support plate			1	
24	30125-00023-00	六角法兰面螺母	Flange nut			3	
25	33013-00215-00	消声器排风下罩	Muffler exhaust hood			1	
26	30101-00407-00	六角法兰面螺栓	Flange bolt			1	
27	33048-00210-00	消声器垫片	Muffler washer			2	
28	30139-00036-00	弹簧垫圈	Spring washer			2	
29	30121-00007-00	六角法兰面螺母	Flange nut			2	
30	20202-00522-00	消声器部件				1	
31	30101-00398-00	六角法兰面螺栓	Flange bolt			2	
32	33013-00214-00	消声器前罩	Muffler front cover			1	
33	30101-00329-00	六角法兰面螺栓	Flange bolt			6	
34	33015-00063-00-	出气口胶套	Outlet rubber sleeve			1	


E-02 覆盖件组件 Overlay component



序号 NO.	零部件编码 Part NO.	零部件名称 Description			数量 QTY		
		中文	English	Price (USD)		SC4000i	N.W. (kg) /PC
1	20133-00001-00	油开关	Fuel tank key			1	
2	30101-00398-00	六角法兰面螺栓	Flange bolt			2	
3	33593-00072-00	固定板	Locating plate			1	
4	30101-00329-00	六角法兰面螺栓	Flange bolt			2	
5		自攻螺丝				3	
6	20135-00233-00	提手后盖				1	
7	20114-03374-01	控制面板总成	Cross-type screw			1	
8							
9	30111-00008-00	十字槽盘头螺钉	Cross-type screw			6	
10	31026-00119-00	燃油开关旋钮				1	
11	30111-00070-00	十字槽盘头螺钉	Cross-type screw			1	
12		自攻螺丝	Self-tapping screws			3	
13	20135-00234-00	提手后盖	Handle cover			1	
14	33013-00086-00	出气盖板	Intake cover			1	
15	33014-00415-00	电池护板	control panel			1	
16	31026-00144-00	旋钮螺栓	Cross recessed pan head screws			1	
17	33013-00089-00	上盖板	Fuel switch knob			1	
18	33015-00064-00	油箱口胶套	Cross recessed pan head screws			1	
19	70009-00068-00	油位口透明块	Self-tapping screws			1	
20	70009-00067-00	夹片螺母	Handle cover			3	
21	33013-00085-00	左侧机壳	Outlet cover			1	
22	70009-00317-00	弹簧夹片	Battery guard			8	
23	33013-00090-00	维修盖板	Knob bolt			1	
24	31026-00145-00	旋钮	Upper cover			1	
25	70009-00067-00	夹片螺母	Fuel tank mouth rubber sleeve			3	
26	33013-00084-00	机器右壳	Oil level port transparent block			1	
27	33014-00686-00	启动保护圈	Clamp nut			1	
28	30125-00008-00	六角法兰面螺母	Flange nut			2	
29	30101-00068-00	六角法兰面螺栓	Flange bolt			2	
30	33013-00088-00	机油窗盖板	Engine oil cover			1	
31	31026-00144-00	旋钮	Knob			1	


序号 NO.	零部件编码 Part NO.	零部件名称 Description			数量 QTY		
		中文	English	Price (USD)		SC4000i	N.W. (kg) /PC
32	30111-00088-00	十字槽盘头螺钉	Cross-type screw			2	
33	30150-00026-00	孔用钢丝挡圈	Wire retaining ring for hole			4	
34	33015-00073-00	电机胶套	Motor rubber sleeve			1	
35	33013-00146-00	进气后盖	Rear intake cover			1	
36	70002-02614-00	接头组件带防尘帽				1	
37	33593-00106-00	手柄挡块				1	
38	30101-00341-00	六角法兰面螺栓	Flange bolt			6	
39	30101-00341-00	六角法兰面螺栓	Flange bolt			6	

E-03 机架组件 Rack components



序号 NO.	零部件编码 Part NO.	零部件名称 Description			数量 QTY		
		中文	English	Price (USD)		SC4000i	N.W. (kg) /PC
1	20184-00020-00	拉杆总成	Tie rod assembly			1	
2	34006-00057-00	定位插销	Positioning latch			2	
3	34006-00016-00	定位销锁紧夹	Locating pin locking clip			2	
4	30101-00407-00	六角法兰面螺栓	Hexagon flange bolts			4	
5	33089-00075-00	拉杆安装板	Tie rod mounting plate			1	
6	30101-00389-00	六角法兰面螺栓	Hexagon flange bolts			4	
7	34040-00086-00	油箱横梁	Fuel tank beam			2	
8	33014-00417-00	支撑架	Support frame			2	
9	33016-00416-00	支撑架	Support frame			2	
10	30125-00023-00	六角法兰面螺栓	Hexagon flange bolts			8	
11	20136-00136-00	逆变器部件	Inverter parts			1	
12	20114-00174-00	逆变器固定支架	Inverter fixing bracket			1	
13	30101-00398-00	六角法兰面螺栓	Hexagon flange bolts			2	
14	33089-00111-00	拉杆安装板	Tie rod mounting plate			1	
15	30101-00407-00	六角法兰面螺栓	Hexagon flange bolts			4	
16	20130-00288-01	燃油箱总成	Fuel tank assembly			1	

E-04 底板组件



序号 NO.	零部件编码 Part NO.	零部件名称 Description			数量 QTY		
		中文	English	Price (USD)		SC4000i	N.W. (kg) /PC
1	70002-02285-00	蓄电池箍带	Battery band			1	
2	20196-00076-00	线束部件	Harness parts			1	
3	20196-00075-00	线束部件	Harness parts			1	
4	31002-00019-00	蓄电池	Accumulator			1	
5	34024-00064-00	夹片螺母	Clamp nut			10	
6	30101-00359-00	六角法兰面螺栓	Hexagon flange bolts			2	
7	34030-00136-00	减震脚垫	Shock Absorber			2	
8	33015-00075-00	密封胶套	Sealing rubber sleeve			1	
9	33015-00074-00	机油口胶套	Engine oil port rubber sleeve			1	

10	33593-00070-00	固定板	Fixed plate			1	
11	30101-00398-00	六角法兰面螺栓	Hexagon flange bolts			4	
12	33593-00079-00	固定板	Fixed plate			1	
13	30125-00023-00	六角法兰面螺母	Hexagon flange nut			8	
14	34030-00101-00	减震座	Shock absorber			4	
15	30101-00398-00	六角法兰面螺栓	Hexagon flange bolts			4	
16	20014-00121-00	底板支架	Floor bracket			1	
17	33089-00074-00	动力底板	Power floor			1	
18	20134-00135-01	轮子总成	Wheel assembly			2	
19	30150-00045-00	轴用弹性挡圈	Circlip for shaft			4	

3.5kW □ □ □ □ □ □ □ □ ○ □ □ □ □ □ □ □

□ □ :SC4000i-O

编制:

校对:

会签:

审核:

批准: