



BT	BHUTAN
----	--------


Diagram / Parts List

DJV182

CORDLESS JIG SAW



(BT) DJV182 / CORDLESS JIG SAW



BT

BHUTAN

DJV182 / CORDLESS JIG SAW

Item	Sub	Parts No.	Parts Description	Qty	I/C	E/C No.	Close No.	Remark
001		187706-8	HOUSING SET	1				
	C10	263005-3	RUBBER PIN 6	2				
	D10		INC. 4					
002		265995-6	TAPPING SCREW 4X18	9				
003		814V65-6	DJV182 NAME PLATE	1				
004		187706-8	HOUSING SET	1				
	C10	263005-3	RUBBER PIN 6	2				
	D10		INC. 1					
005		142303-7	SWITCH PLATE COMPLETE	1				
006		650251-1	SWITCH SGEL106C-4	1				
007		632B56-3	SWITCH UNIT	1				
008		266034-5	TAPPING SCREW CT 4X16	4				
009		142112-4	GEAR HOUSING COVER COMPLETE	1				
010		326302-9	SAFETY WIRE	1				
011		911104-2	PAN HEAD SCREW M4X6	1				
012		454483-0	TOOL OPENER	1				
013		265026-1	+ PAN HEAD SCREW M4	1				
014		231659-4	TORSION SPRING 6	1				
015		346687-7	LINEAR GUIDE	1				
016		232207-2	LEAF SPRING	1				
017		911111-5	PAN HEAD SCREW M4X10 WITH W	4				
018		256117-9	PIN 4	1				
019		214031-5	PLANE BEARING 4	1				
020		961017-7	STOP RING E-3	1				
021		310548-7	SLIDER	1			B9594	
021-1		310837-0	SLIDER	1	<	B9594		
022		268090-1	PIN 4	1				
023		442195-7	GASKET	1				
024		267854-0	CAP WASHER 8	1				
025		421815-6	DUST SEAL 8	1				
026		267854-0	CAP WASHER 8	1				
027		424569-4	DUST COVER	1				
028		962063-3	RETAINING RING R-13	1				
029		165724-6	ROD	1				
030		257347-5	RING 21	1				
031		233591-8	TORSION SPRING 10	1				
032		233314-4	COMPRESSION SPRING 4	1				
033		310485-5	LOCK PIN	1				
034		310547-9	BLADE HOLDER	1				
035		256528-8	PIN 2	1				
036		961002-0	RETAINING RING S-6	1				
037		253715-0	FLAT WASHER 6	1				
038		212014-9	NEEDLE BEARING 407	1			A3527	
038-1		212092-9	NEEDLE BEARING 407	1	O	A3527		
039		142109-3	GEAR COMPLETE	1				
040		313260-8	BALANCE PLATE	1				
041		346688-5	PUSH PLATE	1				
042		253196-8	FLAT WASHER 6	1				
043		454484-8	SEAL PLATE	1				
044		272244-4	LEVER 17	1			A2266	
044-1		272280-0	LEVER 17	1	<	A2266		
045		233139-6	COMPRESSION SPRING 3	1				
046		286032-3	CAP 5	1				
047		268063-4	PIN 4	1				
048		142111-6	GEAR HOUSING COMPLETE	1				
049		961018-5	STOP RING E-5	1				
050		210059-1	BALL BEARING 6000DDW	1				
051		519329-8	ROTOR ASS'Y	1			DK779	
	D10		INC. 50,52				DK779	
051-1		619821-5	ROTOR	1	O	DK779		
	D10		INC. 50			DK779		
052		210022-4	BALL BEARING 626DDW	1			DK779	
053		266490-9	TAPPING SCREW PT 2X6	3				
054		629998-8	STATOR	1				
055		620248-4	CONTROLLER	1			C9013	

A:DJV182Z(N)

Interchange

O : Yes

X : No

< : the new part can be substituted for the current.

> : the current part can be substituted for the new.

S : Interchangeable as a set.

BT

BHUTAN

DJV182 / CORDLESS JIG SAW

Item	Sub	Parts No.	Parts Description	Qty	I/C	E/C No.	Close No.	Remark
055-1		620B24-8	CONTROLLER	1	<	C9013	DE651	
055-2		620B24-8	CONTROLLER	1	O	DE651		
056		643899-6	TERMINAL	1				
057		252171-1	SQUARE NUT M5-8	1				
058		142110-8	RETAINER COMPLETE	1				
059		319016-7	BASE	1				
060		345237-5	CRANK PLATE	1				
061		922231-0	HEX. SOCKET HEAD BOLT M5X20	1				
062		232208-0	LEAF SPRING	1				
063		346685-1	BASE PLATE	1				
064		265085-5	+ COUNTERSUNK HEAD SCREW M4X8	4				
065		135602-4	ROD ASS'Y	1				
	D10		INC. 27-29,31-35					
A01		126331-0	DUST NOZZLE ASSEMBLY	1				
A02		415524-7	ANTI-SPLINTERING DEVICE	1				
A03		417852-6	COVER PLATE	1				
A04		A-85737	JIGSAW BLADE NO.B22	1				
A05		A-85628	JIGSAW BLADE NO.B10	1				
A06		A-85793	JIGSAW BLADE NO.BR13	1				
A07		783202-0	HEX. WRENCH 4	1				
F01		194416-0	SHEET 10000 SET	1		DP447		
F02		192516-0	GUIDE RAIL	1				
F03		192557-6	ANTI-SPLITTING DEVICE	1				
F04		193516-3	GUIDE RULE SET	1				
	C10	165217-3	GUIDE RULE	1				
	C20	271601-3	KNOB 20	1				
	C30	323802-0	GUIDE PIN	1				
	C40	922207-7	HEX. SOCKET HEAD BOLT M5X10	1				
F05-1		193517-1	GUIDE RAIL ADAPTER SET	1	O	C0660		
	C11	265785-7	THUMB SCREW M5X10	1	<	C0660		
	C20	347393-7	RULE BAR	1		C0660		
	C30	417894-0	GUIDE RAIL ADAPTER	1		C0660		
F06		194367-7	GUIDE RAIL 3000 SET	1				
	C10	413102-7	SEAT 3000	2				
	C20	423360-7	POSITION SHEET 3000	1				
	C30	423362-3	RUBBER SEAT 3000	2				
	C40	819212-2	MAKITA LOGO LABEL	1				
F07		194368-5	GUIDE RAIL 1400 SET	1				
	C10	413101-9	SEAT 1400	2				
	C20	423359-2	POSITION SHEET 1400	1				
	C30	423361-5	RUBBER SEAT 1400	2				
	C40	819212-2	MAKITA LOGO LABEL	1				
F08		194925-9	GUIDE RAIL 1900 SET	1				
	C10	423386-9	POSITION SHEET 1900	1				
	C20	423390-8	RUBBER SHEET 1900	2				
	C30	451330-6	SHEET 1900	2				
	C40	819212-2	MAKITA LOGO LABEL	1				
F10-2		197252-3	GUIDE RAIL ADAPTER SET	1	O	C0660		
F17		194417-8	RUBBER SHEET 10000 SET	1		DP447		
F18-3		197606-4	BATTERY BL1830B SET (2PIECES)	1	O	C4176	DR433	
F19-3		197600-6	BATTERY BL1830B SET	1	O	C4176		
F20-4		197599-5	BATTERY BL1830B SET	1	O	DF998		
F21-3		197267-0	BATTERY BL1840B SET	1	O	C5218		
F22-3		197265-4	BATTERY BL1840B SET	1	O	C5218		
F23-3		197273-5	BATTERY BL1840B SET(2PIECES)	1	O	C5218		
F27		199140-0	GUIDE RAIL 1000 SET	1		C0856		
F28		199141-8	GUIDE RAIL 1500 SET	1		C0856		
A:DJV182Z(N)							Interchange O : Yes X : No < : the new part can be substituted for the current. > : the current part can be substituted for the new. S : Interchangeable as a set.	