

# SPARE PARTS LIST

PAGE 1

MODEL NO. PJ7000

| ITEM | PART NO. | DESCRIPTION                          | QTY | NOTE  |
|------|----------|--------------------------------------|-----|-------|
| 001  | 922422-3 | HEX. SOCKET HEAD BOLT M8X16          | 2   |       |
| 002  | 941202-8 | FLAT WASHER 8                        | 2   |       |
| 003  | 453218-6 | GRIP                                 | 1   |       |
| 004  | 266324-6 | TAPPING SCREW 4X22                   | 4   |       |
| 005  | 417771-6 | PIN CAP                              | 1   |       |
| 006  | 234057-1 | COMPRESSION SPRING 8                 | 1   |       |
| 007  | 252186-8 | HEX. NUT M6                          | 1   |       |
| 008  | 227545-5 | SPIRAL BEVEL GEAR 10                 | 1   |       |
| 009  | 213445-5 | O-RING 26                            | 1   |       |
| 010  | 211092-6 | BALL BEARING 629DDW                  | 1   |       |
| 011  | 962105-3 | RETAINING RING R-26                  | 1   |       |
| 012  | 413126-3 | GUIDE PLATE                          | 1   |       |
| 013  | *****    | *****                                | *** | ***** |
| 014  | 517649-4 | ARMATURE ASS'Y 240V<br>INC. 13,15,16 | 1   |       |
| 015  | 681636-0 | INSULATION WASHER                    | 1   |       |
| 016  | 210034-7 | BALL BEARING 607LLB                  | 1   |       |
| 017  | 421868-5 | LABYRINTH RUBBER RING 19             | 1   |       |
| 018  | 450796-7 | BAFFLE PLATE                         | 1   |       |
| 019  | 266325-4 | TAPPING SCREW 4X70                   | 2   |       |
| 020  | *****    | *****                                | *** | ***** |
| 021  | 896483-8 | PJ7000 NAME PLATE                    | 1   |       |
| 022  | 266492-5 | TAPPING SCREW 3X8                    | 2   |       |
| 023  | 643839-4 | BRUSH HOLDER 6X9                     | 2   |       |
| 024  | 194722-3 | CARBON BRUSH CB-459                  | 1   |       |
| 025  | 650621-4 | SWITCH PS10                          | 1   |       |
| 026  | 687681-3 | STRAIN RELIEF                        | 1   |       |
| 027  | 266326-2 | TAPPING SCREW 4X18                   | 1   |       |
| 028  | 645200-1 | NOISE SUPPRESSOR                     | 1   |       |
| 029  | 682569-2 | CORD GUARD 8-85                      | 1   |       |
| 030  | 666015-3 | POWER SUPPLY CORD 1.0-2-2.5          | 1   |       |
| 031  | 266326-2 | TAPPING SCREW 4X18                   | 1   |       |
| 032  | 450794-1 | REAR COVER                           | 1   |       |
| 033  | 450797-5 | SWITCH LEVER                         | 1   |       |
| 034  | 233121-5 | COMPRESSION SPRING 4                 | 1   |       |
| 035  | 450795-9 | MOTOR HOUSING                        | 1   |       |
| 036  | 419566-3 | SWITCH KNOB                          | 1   |       |
| 037  | 213032-0 | O RING 4                             | 1   |       |
| 038  | 256510-7 | SHOULDER PIN 4                       | 1   |       |
| 039  | 141327-0 | GEAR HOUSING COMPLETE                | 1   |       |
| 040  | 210033-9 | BALL BEARING 696ZZ                   | 1   |       |
| 041  | 233950-6 | RING SPRING 11                       | 1   |       |
| 042  | 227546-3 | SPIRAL BEVEL GEAR 37                 | 1   |       |
| 043  | 962151-6 | RETAINING RING R-32                  | 1   |       |
| 044  | 211129-9 | BALL BEARING 6201DDW                 | 1   |       |
| 045  | 326120-5 | SPINDLE                              | 1   |       |
| 046  | 213561-3 | O RING 42                            | 1   |       |
| 047  | 318811-2 | BEARING BOX                          | 1   |       |
| 048  | 911136-9 | PAN HEAD SCREW M4X20                 | 4   |       |
| 049  | 911136-9 | PAN HEAD SCREW M4X20                 | 2   |       |
| 050  | 931203-4 | HEX. NUT M5                          | 1   |       |
| 051  | 266741-0 | PAN HEAD SCREW M5X50                 | 1   |       |
| 052  | 453406-5 | BASE COVER                           | 1   |       |
| 053  | 326145-9 | ROD 10                               | 2   |       |
| 054  | 141247-8 | FENCE COMPLETE                       | 1   |       |
| 055  | 961017-7 | STOP RING E-3                        | 2   |       |

# SPARE PARTS LIST

PAGE 2

MODEL NO. PJ7000

| ITEM | PART NO. | DESCRIPTION                         | QTY | NOTE |
|------|----------|-------------------------------------|-----|------|
| 056  | 256689-4 | PIN 4                               | 2   |      |
| 057  | 318813-8 | BASE                                | 1   |      |
| 058  | 231282-5 | COMPRESSION SPRING 2.4              | 1   |      |
| 059  | 216001-0 | STEEL BALL 3.5                      | 1   |      |
| 060  | 318814-6 | STOPPER                             | 1   |      |
| 061  | 266264-8 | H.S.SET SCREW(FLAT POINT)M5X6       | 2   |      |
| 062  | 266738-9 | +PAN HEAD SCREW M4                  | 1   |      |
| 063  | 213008-7 | O RING 22.4                         | 1   |      |
| 064  | 415252-4 | DUST NOZZLE                         | 1   |      |
| 065  | 265785-7 | THUMB SCREW M5X10                   | 1   |      |
| 066  | 232131-9 | LEAF SPRING                         | 1   |      |
| 067  | 213023-1 | O RING 4                            | 1   |      |
| 068  | 266737-1 | FLAT HEAD SQ. NECK BOLT M6X20       | 1   |      |
| 069  | 231282-5 | COMPRESSION SPRING 2.4              | 1   |      |
| 070  | 216001-0 | STEEL BALL 3.5                      | 1   |      |
| 071  | 231795-6 | TENSION SPRING 8                    | 2   |      |
| 072  | 272263-0 | LEVER 40                            | 1   |      |
| 073  | 252159-1 | HEX. NUT M6                         | 1   |      |
| 074  | 961014-3 | STOP RING E-8                       | 1   |      |
| 075  | 253804-1 | FLAT WASHER 6                       | 1   |      |
| 076  | 224280-6 | INNER FLANGE 40                     | 1   |      |
| 077  | 224505-8 | LOCK NUT 10-40                      | 1   |      |
| 078  | 318845-5 | BLADE COVER                         | 1   |      |
| 079  | 424479-5 | RUBBER SPIKE                        | 2   |      |
| 080  | 213023-1 | O RING 4                            | 1   |      |
| A01  | 123149-0 | ANGLE GUIDE ASSEMBLY<br>COMPO-PARTS | 1   |      |
| A02  | 123150-5 | DUST BAG ASSEMBLY                   | 1   |      |
| A03  | 415579-2 | SET PLATE 4                         | 1   |      |
| A04  | B-20644  | CUTTER 100MMX6T                     | 1   |      |
| A05  | 782401-1 | LOCK NUT WRENCH 20                  | 1   |      |
| A06  | 821509-7 | PLASTIC CARRYING CASE               | 1   |      |
| A07  | 890461-0 | PJ7000 PLASTIC CASE LABEL           | 2   |      |

# SERVICE DRAWING

PAGE 1

MODEL NO. PJ7000

