


AH25 EXPLOSION DRAWING FOR ARGENTTOOLS



AH25 PARTS LIST

ITEM NO.	DESCRIPTION	QTY.	PART NUMBER
1	Bolt M6×40	4	590314
2	Plain washer6	4	650103
3	Coupler	1	115001
4	Front end cover	1	115002
5	Belt assembly	1	115100
6	Screw ST5.5×55-C	4	633303
7	Plain washer 8-140HV	8	650303
8	Supporting bracket	1	190100
9	Stop screw 5×10	1	756003
10	Bolt M8×30	4	590313
11	Supporting spacer	4	190010
12	Armature assembly	1	115200
13	Isolated Washer	1	115210
14	Dust-proof cover 100	1	756008
15	Beating 60100	1	550701
16	Wind-block plate	1	190017
17	End cover	1	190005
18	Plug assembly 1×4. 7	1	115300
19	Rear cover	1	190008
20	Cable protector 9	1	756002
21	Water-proof switch cover	1	190007
22	Bearing 60102	1	550702
23	Breaker 0.2u+4700P×2	1	756009
24	Square adaptor	1	115003
25	Mid-cover	1	115004
26	Rubber washer II	1	190006
27	Cover plate	1	190004
28	Name plate	1	190015
29	Stator assembly	1	115400
30	Screw ST5.5×80-C-H	2	633202
31	Bearing cover	1	756007
32	Motor housing	1	190016
33	Rubber washer I	1	190003
34	Screw ST4.2×25-C	2	633301
35	Brush housing 8×16	2	756005
36	Brush assembly 8×16×18	2	115056
37	Screw ST4.2×13-C-H	2	633201
38	Cable pressing plate	1	756004
39	Screw M4×10	2	633101
40	Switch base	1	190009
41	Switch DPST-16	1	570303
42	Nut screw M8	4	610103
43	Screw ST4.8×90c	4	633302