



BT

BHUTAN

Diagram / Parts List

DLS600

165MM CORDLESS MITER SAW




This exploded view diagram illustrates the assembly of a Makita cordless angle grinder. The main components are shown in their relative positions, with numbered callouts identifying each part. The diagram includes the following parts:

- Motor and Gear Assembly (Top Left):** Includes the motor housing (82), gear housing (81), and various gears (10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30).
- Handle and Trigger Switch (Top Right):** Shows the main handle (99), trigger switch (91), and various internal components like the trigger switch housing (92, 93, 94, 95, 96, 97, 98).
- Guard and Switch (Bottom Left):** Includes the main guard (3), guard switch (4), and various internal components like the guard switch housing (5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30).
- Accessories (Bottom Right):** Shows various accessories like the Makita logo plate (41), Makita logo plate (42), Makita logo plate (43), Makita logo plate (44), Makita logo plate (45), Makita logo plate (46), Makita logo plate (47), Makita logo plate (48), Makita logo plate (49), Makita logo plate (50), Makita logo plate (51), Makita logo plate (52), Makita logo plate (53), Makita logo plate (54), Makita logo plate (55), Makita logo plate (56), Makita logo plate (57), Makita logo plate (58), Makita logo plate (59), Makita logo plate (60), Makita logo plate (61), Makita logo plate (62), Makita logo plate (63), Makita logo plate (64), Makita logo plate (65).

The diagram is a technical illustration showing the exploded view of a Makita cordless angle grinder. It includes the main body, handle, trigger switch, guard, and various accessories. The parts are numbered 1 through 100, with lines indicating their assembly points. The main body is shown in the center, with the handle and trigger switch to the right. The guard and various accessories are shown at the bottom. The diagram is a technical illustration showing the exploded view of a Makita cordless angle grinder. It includes the main body, handle, trigger switch, guard, and various accessories. The parts are numbered 1 through 100, with lines indicating their assembly points. The main body is shown in the center, with the handle and trigger switch to the right. The guard and various accessories are shown at the bottom.

(BT) DLS600 / 165MM CORDLESS MITER SAW



BT

BHUTAN

DLS600 / 165MM CORDLESS MITER SAW

Item	Sub	Parts No.	Parts Description	Qty	I/C	E/C No.	Close No.	Remark
001		265491-4	H.S. BUTTON HEAD BOLT M5X16	1				
002		267136-0	FLAT WASHER 5	1				
003		458077-3	SAFETY COVER	1				
004		265008-3	+ FLAT HEAD SCREW M5	1				
005		232311-7	TORSION SPRING 30	1				
006		210150-5	BALL BEARING 6803DDW	1			DW997	
006-1		210322-2	BALL BEARING 6803DDW	1	O	DW997		
007		266732-1	HEX. SOCKET HEAD BOLT M6X16	1				
008		347060-4	CENTER COVER	1				
009		347059-9	CENTER PLATE	1				
010		266733-9	HEX. S.F.H. BOLT M6X16	1				
011		224405-2	OUTER FLANGE 35	1				
012		224593-5	INNER FLANGE 35	1				
013		325866-0	SPINDLE	1				
014		911128-8	P.H.SCREW M4X16 WITH WR	4				
015		347295-7	BEARING RETAINER	1				
016		211288-9	BALL BEARING 6901DDW	1				
017		318534-2	BEARING BOX	1				
018		442152-5	GASKET	1				
019		227727-9	HELICAL GEAR 39	1				
020		961052-5	RETAINING RING (EXT) S-12	1				
021		210006-2	BALL BEARING 696ZZ	1				
022		210017-7	BALL BEARING 607DDW	1				
023		227726-1	HELICAL GEAR 31	1				
024		254011-9	WOODRUFF KEY 4	1				
025		227565-9	SPIRAL BEVEL GEAR 35	1				
026		253744-3	FLAT WASHER 12	1				
027		261104-5	RUBBER WASHER 12	1				
028		253744-3	FLAT WASHER 12	1				
029		961052-5	RETAINING RING (EXT) S-12	1				
030		210005-4	BALL BEARING 608DDW	1				
038		266026-4	TAPPING SCREW BIND CT 4X12	1				
039		346171-2	COVER PLATE	1				
040		144796-4	BLADE CASE COMPLETE	1				
	C10	263002-9	RUBBER PIN 4	4				
	C20	263005-3	RUBBER PIN 6	1				
041		424870-7	GUARD	1				
042		347057-3	GUARD PLATE	1				
043		911113-1	PAN HEAD SCREW M4X10 WITH WR	1				
044		266026-4	TAPPING SCREW BIND CT 4X12	1				
045		458075-7	LEAD COVER	1				
048		266229-0	H.S.SET SCREW(CUP POINT)M5X8	1				
049		233471-8	COMPRESSION SPRING 6	1				
050		418104-8	LENS	1				
051		266306-8	SHOULDER SCREW M5	1				
052		266318-1	H.S.SET SCREW(FLAT POINT)M4X6	1				
053		419379-2	BLOCK C	1				
054		231664-1	TORSION SPRING 9	1				
055		911003-8	PAN HEAD SCREW M3X6	1				
056		419378-4	BLOCK B	1				
057		911003-8	PAN HEAD SCREW M3X6	1				
058		231664-1	TORSION SPRING 9	1				
059		266318-1	H.S.SET SCREW(FLAT POINT)M4X6	1				
060		638442-4	LASER CIRCUIT COMPLETE	1				
061		140344-7	LASER COVER COMPLETE	1				
062		266229-0	H.S.SET SCREW(CUP POINT)M5X8	1				
063		253807-5	FLAT WASHER 5	1				
064		265753-0	THUMB SCREW M5X24	1				
065		266042-6	TAPPING SCREW BIND CT 4X20	2				
066		231240-1	COMPRESSION SPRING 7	1				
067		256633-1	PIN 6	1				
068		231928-3	RING SPRING 8	1				
069		519400-8	ROTOR ASSEMBLY	1				
	D10		INC. 70,71					
070		211131-2	BALL BEARING 6001DDW	1				

A:DLS600Z(N)

Interchange

O : Yes

X : No

< : the new part can be substituted for the current.

> : the current part can be substituted for the new.

S : Interchangeable as a set.

BT

BHUTAN

DLS600 / 165MM CORDLESS MITER SAW

Item	Sub	Parts No.	Parts Description	Qty	I/C	E/C No.	Close No.	Remark
071		210017-7	BALL BEARING 607DDW	1				
072		213021-5	O RING 5	1				
073		326769-1	STOPPER PIN	1				
074		253842-3	FLAT WASHER 14	1				
075		261153-2	URETHAN WASHER 15	1				
076		265995-6	TAPPING SCREW 4X18	2				
077		961018-5	STOP RING E-5	1				
079		144033-6	INDICATION PLATE COMPLETE	1				
080		456908-0	BAFFLE PLATE	1				
081-1		629B61-9	STATOR	1				
082		456910-3	MOTOR HOUSING	1				
083		853T32-4	DLS600 NAME PLATE	1				
084		911278-9	PAN HEAD SCREW M5X55	2				
085		911268-2	PAN HEAD SCREW M5X45	2				
086		256123-4	PIN 5	1				
087-1		620C12-1	LED CIRCUIT	1				
088		265995-6	TAPPING SCREW 4X18	2				
089		911268-2	PAN HEAD SCREW M5X45	1				
090		417113-4	SWITCH BUTTON	1				
091		183E52-7	HANDLE SET	1				
	C10	263005-3	RUBBER PIN 6	2				
	D10		INC. 99					
092		643874-2	TERMINAL	1				
093-1		620L27-2	CONTROLLER A	1				
094		231026-3	COMPRESSION SPRING 4	1				
095		416533-9	LOCK OFF LEVER	1				
096		452130-7	SWITCH LEVER	1				
097		650705-8	SWITCH TG73BDS-1	1				
098		620551-3	POWER SUPPLY CIRCUIT	1				
099		183E52-7	HANDLE SET	1				
	C10	263005-3	RUBBER PIN 6	2				
	D10		INC. 91					
100		265995-6	TAPPING SCREW 4X18	6				
101		266757-5	HEX. SOCKET HEAD BOLT M6X16	1				
102		251961-9	H.S.SET SCREW(FLAT POINT)M6X10	1				
103		331350-5	PIN 16-90	1				
104		416535-5	SLEEVE 17	1				
105		232310-9	TORSION SPRING 28	1				
106		416535-5	SLEEVE 17	1				
107		961018-5	STOP RING E-5	1				
108		253804-1	FLAT WASHER 6	1				
109		257163-5	RING 6	1				
110		144791-4	LINK PLATE COMPLETE	1				
111		922331-6	HEX. SOCKET HEAD BOLT M6X20	1				
112		253804-1	FLAT WASHER 6	1				
113		257163-5	RING 6	1				
114		266026-4	TAPPING SCREW BIND CT 4X12	1				
115-1		458646-0	INDICATION PLATE	1				
116		144795-6	ARM COMPLETE	1				
	C10	816438-7	OPERATIONAL INDICATION LABEL	1				
117		687045-1	STRAIN RELIEF	1				
118		266034-5	TAPPING SCREW CT 4X16	1				
119		416006-2	LEVER 100	1				
120		911113-1	PAN HEAD SCREW M4X10 WITH WR	1				
121		251495-2	HEX. BOLT M10	1				
122		253024-7	FLAT WASHER 10	1				
123		272266-4	LEVER 25	1				
124		233563-3	TORSION SPRING 8	1				
125		415208-7	RELEASE BUTTON	1				
126		233031-6	COMPRESSION SPRING 12	1				
127		253726-5	FLAT WASHER 6	1				
128		961018-5	STOP RING E-5	1				
129		318533-4	STOPPER	1				
130		231646-3	TORSION SPRING 14	1				
131		253744-3	FLAT WASHER 12	1				

A:DLS600Z(N)

Interchange

O : Yes

X : No

< : the new part can be substituted for the current.

> : the current part can be substituted for the new.

S : Interchangeable as a set.

BT | BHUTAN

DLS600 / 165MM CORDLESS MITER SAW

[illegible]