
Assemble Instruction for YF-8573-3




A 1 PC	B 1 PC	C 1 PC	D 1 PC	K 1 PC
M6X18	M6X35	0	М6X55 ()—шш	
E 4 PCS	F 6 PCS	G 15 PCS	J 5 PC	H 1 PC



Assemble Instruction for YF-8573-1



A 1 PC	B 1 PC	C 1 PC	D 1 PC
M6X35	M6X55	0	
F 6 PCS	J 4 PCS	G 10 PCS	H 1 PC



Assemble Instruction for YF-8573T

