


1 CRANK CASE GROUP


FIG. 100



1 CRANK CASE GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.
10	20A-10103-11	CRANK CASE CP	1		曲轴箱组件		100
	20A-10103-01	CRANK CASE CP	1		曲轴箱组件		100
	20A-10103-02	CRANK CASE UN			曲轴箱		
26	20A-16010-01	STEM SEAL	1		气门油封		100
30	20A-04801-00	OIL SEAL	1		油封		100
40	20A-06101-00	BALL BEARING	1		轴承		100
50	20A-15011-03	PIPE KNOCK	2		定位销		100
60	20A-01611-00	STUD	2		双头螺栓		100
70	20A-01601-00	STUD	2		双头螺栓		100
75	20A-04802-00	OIL SEAL	1		油封		100
80	20A-04101-00	PLUG	2		放油螺栓		100
90	20A-02202-00	GASKET	2		垫片		100
210	20A-11002-01	MAINBEARING COVER CP	1		曲轴箱盖组件		100
220	20A-04803-00	OIL SEAL	1		油封		100
230	20A-06102-00	BALL BEARING	1		滚珠轴承		100
250	20A-45004-01	GOVERNOR GEAR CP	1		调速齿轮		100
260	20A-41901-03	GOVERNOR SLEEVE	1		调速套筒		100
285	20A-63601-00	OIL GAUGE AY	2		油标尺		100
300	20A-01101-00	FLANGE BOLT	6		法兰螺栓		100
610	20A-13001-01	CYLINDER HEAD CP	1		气缸头组件		100
	20A1300102	CYLINDER HEAD	1				
620	20A-15001-03	GASKET (HEAD)	1		气缸头垫片		100
630	20A-01102-00	FLANGE BOLT	4		法兰螺栓		100
631	20A-01103-00	FLANGE BOLT	1		法兰螺栓		100
680	20A-15505-01	ROCKER COVER CP	1		缸盖罩		100
690	20A-16001-13	GASKET (ROCKER COVER)	1		垫片(缸盖罩)		100
700	20A-15011-03	PIPE KNOCK	2		定位销		100
710	20A-01111-00	FLANGE BOLT	4		法兰螺栓		100

FIG. 200




2 CRANKSHAFT, PISTON GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
10	20A-21201-11	CRANK SHAFT CP	1		曲轴		200	
50	20A-01853-00	FLANGE NUT	1		法兰螺母		200	
70	20A-03601-00	WOODRUFF KEY	1		半圆键		200	
80	20A-03612-00	KEY	1		曲轴平键		200	
310	20A-22501-10	CONNECTING ROD AY	1		连杆总成		200	
350	20A-23301-03	PISTON PIN	1		活塞销		200	
360	20A-23401-03	PISTON	1		活塞		200	
375	20A-23611-03	TOP RING	1		一环		200	
376	20A-23711-03	SECOND RING	1		二环		200	
377	20A-23931-01	OIL RING CP	1		油环组合		200	
380	20A-03201-00	CLIP	2		活塞销挡圈		200	

3 INTAKE, EXHAUST GROUP

FIG. 300



3 INTAKE, EXHAUST GROUP


REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.
10	20A-31601-01	CAM SHAFT CP	1		凸轮轴		300
23	20A-35101-01	PIN(CAM SHAFT)CP	1		销轴(凸轮轴)		300
27	20A-02801-00	O RING	1		O型圈		300
60	20A-33601-03	VALVE SPRING	2		气门弹簧		300
70	20A-33701-03	SPRING RETAINER	2		气门弹簧盘		300
80	20A-33401-03	INTAKE VALVE	1		进气门		300
90	20A-33501-03	EXHAUST VALVE	1		排气门		300
95	20A-33801-03	COLLET-VALVE	4		气门卡锁		300
150	20A-35601-01	TIMING CHAIN CP	1		正时链条		300
160	20A-36911-03	TENTIONER	1		张紧器		300
163	20A-37101-03	SPRING(TENTIONER)	1		弹簧(张紧器)		300
166	20A-36902-03	PIN(TENTIONER)	1		销(张紧器)		300
170	20A-36913-03	CHAIN GUIDE	1		链条导向板		300
200	20A-35004-01	PIN(ROCKER) CP	1		摇臂销		300
202	20A-03211-00	CLIP	1		卡簧		300
220	20A-36201-00	ROCKER ARM(IN) AY	1		摇臂(进气)		300
225	20A-36202-00	ROCKER ARM(EX) AY	1		摇臂(排气)		300
290	20A-01111-00	FLANGE BOLT	1		法兰螺栓		300

3 INTAKE, EXHAUST GROUP


REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
310	20A-30101-11	MUFFLER CP	1		消声器		300	
320	20A-34201-10	MUFFLER COVER CP	1		消声器罩		300	
340	20A-35201-03	GASKET (MUFFLER)	1		垫片 (消声器)		300	
350	20A-01851-20	FLANGE NUT	2		法兰螺母		300	
360	20A-01201-00	TAPPING BOLT	2		自攻螺栓		300	
361	20A-01112-00	FLANGE BOLT	1		法兰螺栓		300	
365	20A-01104-00	FLANGE BOLT	1		法兰螺栓		300	
367	20A-02101-00	WASHER	1		垫圈		300	
540	20A-32902-01	INSULATOR CP	1		绝缘隔热板		300	
550	20A-35903-03	GASKET 2 (INSULATOR)	1		垫片 (绝缘隔热板)		300	
560	20A-35902-03	GASKET 1 (INSULATOR)	1		垫片 (绝缘隔热板)		300	
570	20A-01852-00	FLANGE NUT	2		法兰螺母		300	
580	20A-01113-00	FLANGE BOLT	1		法兰螺栓		300	
850	20A-08111-00	RUBBER PIPE	1		橡胶管		300	

FIG. 325

DUAL ELEMENT



URETHANE FOAM



3 INTAKE, EXHAUST GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
						部品番号		
510	20A-32633-00	AIR CLEANER AY	1		空滤总成	DUAL	325	
520	20A-32636-00	ELEMENT AY	1		滤芯		325	
530	20A-32614-03	PACKING	1		空滤器垫片		325	
910	20A-32615-03	LABEL	1		标签（阻风门）		325	

The diagram illustrates the assembly of a vehicle's rear suspension system. The main assembly view shows the following components and their assembly sequence:

- 13**: A bracket or support structure.
- 70**: A bush or spacer.
- 10**: A control arm or similar structural member.
- 60**: A bolt or nut used for securing the control arm.
- 80, 81**: A spring or shock absorber component.
- 40**: A spring or shock absorber component.
- 30**: A structural member or frame part.
- 450**: A small circular component, possibly a washer or bush.
- 340**: A circular component, possibly a bush or washer.
- 350**: A circular component, possibly a bush or washer.
- 310**: A bracket or support structure.
- 322**: A small component, possibly a pin or clip.
- 480**: A spring or shock absorber component.
- 355**: A circular component, possibly a bush or washer.
- 440**: A small component, possibly a pin or clip.
- 485**: A bolt or nut used for securing the assembly.
- 360**: A bolt or nut used for securing the assembly.
- 370**: A spring or shock absorber component.
- 365**: A spring or shock absorber component.
- 345**: A bolt or nut used for securing the assembly.
- 396**: A small component, possibly a pin or clip.
- 395**: A small component, possibly a pin or clip.
- 435**: A bracket or support structure.
- 20**: A structural member or frame part.
- 50**: A bolt or nut used for securing the assembly.


The inset diagram, labeled **GENERATOR**, shows a detailed view of the generator component, which includes the following parts:

- 310**: A bracket or support structure.
- 360**: A bolt or nut used for securing the assembly.
- 370**: A spring or shock absorber component.
- 365**: A spring or shock absorber component.

4 GOVERNOR OPERATION GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
13	20A-42301-00	GOVERNOR LEVER AY	1		摆动杆		400	
20	20A-42201-03	GOVERNOR SHAFT	1		调速器推杆		400	
30	20A-42701-01	GOVERNOR ROD CP	1		调速器拉杆		400	
40	20A-42801-03	ROD SPRING	1		拉杆拉簧		400	
50	20A-03211-00	CLIP	1		卡簧		400	
80	20A-42510-03	GOVERNOR SPRING	1		调速弹簧		400	
310-480	20A-46502-00	SPEED CONT AY	1		调速机构部件		400	
485	20A-01111-00	FLANGE BOLT	2		法兰螺栓		400	


FIG. 500



5 COOLING, STARTING GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
10	20A-51203-11	BLOWER HOUSING CP	1		导风罩		500	
20		LABEL (TRADE MARK)	1		标签 (商标)		500	
40	20A-01114-00	FLANGE BOLT	4		法兰螺栓		500	
60	20A-52711-01	BAFFLE 1 (CASE) CP	1		箱体导风板		500	
61	20A-52702-01	BAFFLE 2 (HEAD) CP	1		缸头导风板		500	
80	20A-01115-00	FLANGE BOLT	1		法兰螺栓		500	
81	20A-01111-00	FLANGE BOLT	1		法兰螺栓		500	
110	20A-54101-13	COOLING BLOWER	1		风扇		500	
220	20A-01114-00	FLANGE BOLT	4		法兰螺栓		500	


FIG. 522



5 COOLING, STARTING GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
210	20A-50201-30	RECOIL STARTER AY	1		起动机部件		522	


This exploded perspective view shows the assembly of a mechanical device. The main body (10) is a square-shaped housing with a central circular opening. A cap (20, 21) is shown above the opening, secured by a cap screw (46) and a washer (45). A gasket (40) is positioned between the cap and the body. A rectangular plate (23) and a cylindrical component (24) are shown to the right of the body. A bolt (60) is shown at the bottom left of the body. A bracket (63) is shown on the right side of the body. A vertical pipe (70) is shown below the body, with a horizontal pipe (80) connected to it. A valve (90) is shown on the horizontal pipe. A handle (185) is shown on the valve. A bolt (188) is shown on the handle. A pump (224) is shown at the bottom left of the vertical pipe. A valve (510) is shown on the horizontal pipe, with a bolt (522) shown below it. A bolt (80) is shown on the right side of the horizontal pipe.



6 FUEL, LUBRICANT GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
10	20A-61101-11	FUEL TANK CP	1		燃油箱		600	
20	X73-20057-60	LABEL(WARNING)	1		标签（警示标签）		600	
23	20A-09709-00	LABEL(EX17)	1		型号标签（EX17）		600	
30	20A-04401-00	FUEL TANK CAP CP	1		油箱盖		600	
40	20A-06401-00	FUEL FILTER	1		油箱滤网		600	
48	20A-06402-00	UNION	1		油嘴组		600	
60	20A-01852-00	FLANGE NUT	2		法兰螺母		600	
63	20A-01116-00	FLANGE BOLT	1		法兰螺栓		600	
70	20A-62605-01	FUEL PIPE CP	1		燃油管		600	
80	20A-08104-00	RUBBER PIPE	1		橡胶管		600	
90	20A-05804-00	HOSE CLAMP	2		管夹		600	
224	20A-43801-01	CHOKE LEVER CP	1		阻风门手柄		600	


FIG. 640



6 FUEL, LUBRICANT GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
210	20A-62302-60	CARBURETOR AY	1		化油器总成		640	

FIG. 700



7 ELECTRIC DEVICE GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
10	20A-79231-01	FLYWHEEL CP	1		飞轮		700	
11	20A-79431-01	IGNITION COIL CP	1		点火线圈		700	
30	20A-01302-00	BOLT AND WASHER AY	2		螺栓组合件		700	
50	20A-73101-01	WIRE 1 CP	1		熄火线1		700	
60	20A-06601-00	SWITCH AY	1		停止开关			
70	20A-01403-00	TAPPING SCREW	2		螺丝			
100	20A-06701-00	SPARK PLUG	1		火花塞		700	
110	22E-06801-00	SPARK PLUG CAP	1		火花塞帽		700	