



FIG. 100



1 CRANK CASE GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK		FIG.
10	22E-10101-01	CRANKCASE CP	1		曲轴箱组件		100
26	20A-16010-01	STEM SEAL	1		气门油封		100
30	22E-04801-00	OIL SEAL	1		油封		100
40	22E-06101-00	BALL BEARING	1		轴承		100
50	20A-15011-03	PIPE KNOCK	2		定位销		100
60	20A-01611-00	STUD	2		嵌入式螺栓		100
70	22E-01601-00	STUD	2		嵌入式螺栓		100
75	20A-04802-00	OIL SEAL	1		油封		100
80	20A-04101-00	PLUG	2		放油螺栓		100
90	20A-02201-00	GASKET	2		垫片		100
210	22E-11002-01	MAINBEARING COVER C	1		曲轴箱盖组件		100
220	22E-04801-00	OIL SEAL	1		油封		100
230	22E-06101-00	BALL BEARING	1		滚珠轴承		100
250	20A-45004-01	GOVERNOR GEAR CP	1		调速齿轮		100
260	20A-41901-03	GOVERNOR SLEEVE	1		调速套筒		100
280	22E-02301-00	GASKET	2		垫片		100
285	22E-63601-00	OIL GAUGE AY	2		油尺总成		100
300	20A-01101-00	FLANGE BOLT	7		法兰螺栓		100
610	22E-13001-01	CYLINDER HEAD CP	1		气缸头组件		100
620	22E-15001-03	GASKET (HEAD)	1		气缸头垫片		100
630	20A-01102-00	FLANGE BOLT	4		法兰螺栓		100
631	20A-01103-00	FLANGE BOLT	1		法兰螺栓		100
680	20A-15505-01	ROCKER COVER CP	1		缸盖罩		100
690	20A-16001-13	GASKET(ROCKER COVER	1		垫片(缸盖罩)		100
700	20A-15011-03	PIPE KNOCK	2		定位销		100
710	20A-01111-00	FLANGE BOLT	4		法兰螺栓		100

FIG. 200




2 CRANKSHAFT,PISTON GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK		FIG.
						部品番号	
10	22E-20901-01	CRANK SHAFT CP	1				200
	22G-01851-00	nut	1				200
70	20A-03601-00	WOODRUFF KEY	1				200
80	22G--26001-03	KEY	1				200
90	22E-02101-00	WASHER	1				200
100	20A-01105-00	FLANGE BOLT	1				200
310	22E-22501-00	CONNECTING ROD AY	1				200
350	22E-23301-03	PISTON PIN	1				200
360	22E-23401-03	PISTON	1				200
375	22E-23601-03	TOP RING	1				200
376	22E-23701-03	SECOND RING	1				200
377	22E-23921-03	OIL RING CP	1				200
380	22E-03201-00	CLIP	2				200

EX270 FIG.300

3 INTAKE, EXHAUST GROUP

FIG. 300



3 INTAKE, EXHAUST GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK		FIG.
10	22E-31601-01	CAMSHAFT CP	1				300
25	20A-35101-01	PIN(CAM SHAFT)CP	1				300
27	20A-02801-00	O RING	1				300
60	20A-33601-03	VALVE SPRING	2				300
70	20A-33701-03	SPRING RETAINER	2				300
80	22E-33401-03	INTAKE VALVE	1				300
90	22E-33501-03	EXHAUST VALVE	1				300
95	20A-33801-03	COLLET-VALVE	4				300
150	22E-35602-01	TIMING CHAIN CP	1				300
160	20A-36911-03	TENTIONER	1				300
163	20A-37101-03	SPRING(TENTIONER)	1				300
166	20A-36902-03	PIN(TENTIONER)	1				300
170	20A-36913-03	CHAIN GUIDE	1				300
200	20A-35004-01	PIN(ROCKER) CP	1				300
202	20A-03211-00	CLIP	1				300
220	20A-36201-00	ROCKER ARM(IN) AY	1				300
225	20A-36202-00	ROCKER ARM(EX) AY	1				300
290	20A-01111-00	FLANGE BOLT	1				300
310	22E-30101-01	MUFFLER CP	1				300


3 INTAKE, EXHAUST GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK		FIG.
320	22E-34201-01	MUFFLER COVER CP	1		消声器罩		300
340	20A-35201-03	GASKET(MUFFLER)	1		垫片(消声器)		300
350	20A-01851-20	FLANGE NUT	2		法兰螺母		300
360	20A-01201-00	TAPPING BOLT	2		自攻螺栓		300
361	20A-01112-00	FLANGE BOLT	1		法兰螺栓		300
365	20A-01104-00	FLANGE BOLT	1		法兰螺栓		300
387	20A-01402-00	TAPPING SCREW	2		自攻螺栓		300
440	20A-37001-11	DEFLECTOR CP	1		排气导向器		300
540	22E-32902-01	INSULATOR CP	1		绝缘隔热板		300
550	22E-35903-03	GASKET2(INSULATOR)	1		垫片(绝缘隔热板)		300
560	22E-35902-03	GASKET1(INSULATOR)	1		垫片(绝缘隔热板)		300
570	20A-01852-00	FLANGE NUT	2		法兰螺母		300
580	20A-01121-00	FLANGE BOLT	1		法兰螺栓		300
850	22E-08102-00	RUBBER PIPE	1		橡胶管		300

EX270 FIG.316

3 INTAKE, EXHAUST GROUP


FIG. 316



3 INTAKE, EXHAUST GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	部品番号	FIG.
510	22E-32631-00	AIR CLEANER AY	1		空滤总成		316
512	22E-32633-02	BASE UN	1		空滤基座		316
514	22E-32632-01	COVER CP	1		空滤壳体盖		316
516	22E-32639-03	WING NUT	1		蝶型螺母		316
517	20A-32806-03	WING NUT	1		蝶型螺母		316
520	22E-32636-00	ELEMENT AY	1		滤芯		316
530	22E-32624-03	GASKET	1		垫片		316
533	22E-32635-03	PACKING	1		垫圈		316
910	20A-32615-03	LABEL	1		标签(阻风门)		316

FIG. 400




4 GOVERNOR OPERATION GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK		FIG.
						部品番号	
13	22E-42301-00	GOVERNOR LEVER AY	1		摆动杆		400
20	20A-42201-03	GOVERNOR SHAFT	1		调速器推杆		400
30	22E-42701-01	GOVERNOR ROD CP	1		调速器拉杆		400
40	20A-42801-03	ROD SPRING	1		拉杆拉簧		400
50	20A-03211-00	CLIP	1		卡圈		400
80	20A-42510-03	GOVERNOR SPRING	1		调速弹簧		400
310-48	20A-46002-00	SPEED CONT AY	1		速度控制杆		400
485	20A-01111-00	FLANGE BOLT	2		法兰螺栓		400

EX270 FIG.500

5 COOLING, STARTING GROUP



FIG. 500



5 COOLING, STARTING GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK		FIG.
						部品番号	
10	22E-51201-01	BLOWER HOUSING CP	1		导风罩		500
40	20A-01114-00	FLANGE BOLT	4		法兰螺栓		500
60	22E-52711-01	BAFFLE 1(CASE) CP	1				500
61	22E-52702-01	BAFFLE 2(HEAD) CP	1				500
80	22G-01201-00	BOLT	1		螺栓		500
81	20A-01111-00	FLANGE BOLT	1		法兰螺栓		500
220	22G-01301-00	BOLT AND WASHER AY	4				500



FIG. 520



5 COOLING, STARTING GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK		FIG.	
210	22E-50301-00	RECOIL STARTER AY	1		起动拉盘总成		520	

FIG. 600




6 FUEL, LUBRICANT GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK		FIG.
	22E6015100	FUEL TANK AY	1				600
10	22E-60101-01	FUEL TANK CP	1			ROBIN YELLOW	600
20	X73-20057-60	LABEL(WARNING)	1				600
23	22E-95112-03	LABEL(MODEL)	1				600
30	20A-04401-00	FUEL TANK CAP CP	1				600
40	20A-06401-00	FUEL FILTER	1				600
48	20A-06402-00	UNION	1				600
60	20A-01851-20	FLANGE NUT	2				600
63	20A-01105-00	FLANGE BOLT	2				600
70	22E-62602-01	FUEL PIPE CP	1				600
80	22E-08101-00	RUBBER PIPE	1				600
85	22E-64502-01	GLASS TUBE	1				600
90	20A-05801-00	HOSE CLAMP	2				600
224	20A-43801-01	CHOKE LEVER CP	1				600

6 FUEL, LUBRICANT GROUP

FIG. 640




6 FUEL, LUBRICANT GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK		FIG.
210	22E-62362-00	CARBURETOR AY	1		化油器		640

EX270 FIG.700

7 ELECTRIC DEVICE GROUP

FIG. 700




7 ELECTRIC DEVICE GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	FIG.
10	22E-79230-01	FLYWHEEL CP	1			700
11	22E-79430-01	IGNITION COIL CP	1			700
30	20A-01302-00	BOLT AND WASHER AY	2			700
50	20A-73101-01	WIRE 1 CP	1			700
60	22G-06601-00	SWITCH AY	1			700
70	20A-01403-00	TAPPING SCREW	2			700
100	20A-06701-00	SPARK PLUG	1			700
110	22E-06801-00	SPARK PLUG CAP	1			700

EX270 FIG.770

7 ELECTRIC DEVICE GROUP

FIG. 770




700	279-76301-61	OIL SENSOR CP	1				770
-1	277-76350-08	O RING	1				770
705	KU3-11071-01	FLOAT C/U CP4	1				770
733	20A-75801-03	SHIELD PLATE(O/S)	1				770
740	20A-01120-00	FLANGE BOLT	2				770
741	20A-01201-00	TAPPING BOLT	2				770
770	22E-75501-01	WIRE CLAMP	1				770
780	20A-05901-00	PURSE LOCK	1				770

EX270 FIG.900

9 ACCESSORIES, LABEL

FIG. 900



9 ACCESSORIES LABEL

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK		FIG.	
10		ACCESSORY TOOL KIT	1		随机工具		900	
	20A-99969-01	OWNERS MANUAL AY	1		说明书	19 languages	900	