


1 CRANK CASE

FIG. 100




1 CRANK CASE

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK		FIG.	
10	21D-10101-11	CRANKCASE CP	1				100	
	21D-10101-01	CRANK CASE CP	1				100	
26	20A-16010-01	STEM SEAL	1				100	
30	20A-04801-00	OIL SEAL	1				100	
40	20A-06101-00	BALL BEARING	1				100	
50	20A-15011-03	PIPE KNOCK	2				100	
60	20A-01611-00	STUD	2				100	
70	20A-01601-00	STUD	2				100	
75	20A-04802-00	OIL SEAL	1				100	
80	20A-04101-00	PLUG	2				100	
90	20A-02202-00	GASKET	2				100	
210	20A-11001-01	MAINBEARING COVER CP	1				100	
220	20A-04803-00	OIL SEAL	1				100	
230	20A-06102-00	BALL BEARING	1				100	
250	20A-45004-01	GOVERNOR GEAR CP	1				100	
260	20A-41901-03	GOVERNOR SLEEVE	1				100	
285	20A-63601-00	OIL GAUGE AY	2				100	
300	20A-01101-00	FLANGE BOLT	6				100	
610	21D-13001-01	CYLINDER HEAD CP	1				100	
620	20A-15001-03	GASKET (HEAD)	1				100	
630	20A-01102-00	FLANGE BOLT	4				100	
631	20A-01103-00	FLANGE BOLT	1				100	
680	20A-15505-01	ROCKER COVER CP	1				100	
690	20A-16001-13	GASKET (ROCKER COVER)	1				100	
700	20A-15011-03	PIPE KNOCK	2				100	
710	20A-01111-00	FLANGE BOLT	4				100	

2 CRANKSHAFT, PISTON


FIG. 200



2 CRANKSHAFT, PISTON

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	FIG.
10	21D-21201-11	CRANK SHAFT CP	1			200
50	20A-01853-00	FLANGE NUT	1			200
70	20A-03601-00	WOODRUFF KEY	1			200
80	20A-03613-00	KEY	1			200
310	21D-22501-00	CONNECTING ROD AY	1			200
350	20A-23301-03	PISTON PIN	1			200
360	20A-23401-03	PISTON	1			200
375	20A-23611-03	TOP RING	1			200
376	20A-23711-03	SECOND RING	1			200
377	20A-23931-01	OIL RING CP	1			200
380	20A-03201-00	CLIP	2			200

FIG. 300




3 INTEK EXHAUST

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK		FIG.
10	20A-31601-01	CAM SHAFT CP	1				300
23	20A-35101-01	PIN (CAM SHAFT) CP	1				300
27	20A-02801-00	O RING	1				300
60	20A-33601-03	VALVE SPRING	2				300
70	20A-33701-03	SPRING RETAINER	2				300
80	20A-33401-03	INTAKE VALVE	1				300
90	20A-33501-03	EXHAUST VALVE	1				300
95	20A-33801-03	COLLET-VALVE	4				300
150	21D-35601-01	TIMING CHAIN CP	1				300
160	20A-36911-03	TENTIONER	1				300
163	20A-37101-03	SPRING (TENTIONER)	1				300
166	20A-36902-03	PIN (TENTIONER)	1				300
170	20A-36913-03	CHAIN GUIDE	1				300
200	20A-35004-01	PIN (ROCKER) CP	1				300
202	20A-03211-00	CLIP	1				300
220	20A-36201-00	ROCKER ARM (IN) AY	1				300
225	20A-36202-00	ROCKER ARM (EX) AY	1				300
290	20A-01111-00	FLANGE BOLT	1				300
310	20A-30101-11	MUFFLER CP	1				300
320	20A-34201-10	MUFFLER COVER CP	1				300
340	20A-35201-03	GASKET (MUFFLER)	1				300
350	20A-01851-20	FLANGE NUT	2				300
360	20A-01201-00	TAPPING BOLT	2				300
361	20A-01112-00	FLANGE BOLT	1				300
365	20A-01104-00	FLANGE BOLT	1				300
367	20A-02101-00	WASHER	1				300
540	20A-32902-01	INSULATOR CP	1				300
550	20A-35903-03	GASKET 2 (INSULATOR)	1				300
560	20A-35902-03	GASKET 1 (INSULATOR)	1				300
570	20A-01852-00	FLANGE NUT	2				300
580	20A-01113-00	FLANGE BOLT	1				300
850	20A-08111-00	RUBBER PIPE	1				300


3 INTAKE EXHAUST

FIG. 325

DUAL ELEMENT



URETHANE FOAM




3 INTAKE EXHAUST

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	FIG.
510	20A-32633-00	AIR CLEANER AY	1			325
520	20A-32636-00	ELEMENT AY	1			325
530	20A-32614-03	PACKING	1			325
910	20A-32615-03	LABEL	1			325

4 GOVERNOR OPERATION

FIG. 400



4 GOVERNOR OPERATION

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	FIG.
13	20A-42301-00	GOVERNOR LEVER AY	1			400
20	20A-42201-03	GOVERNOR SHAFT	1			400
30	20A-42701-01	GOVERNOR ROD CP	1			400
40	20A-42801-03	ROD SPRING	1			400
50	20A-03211-00	CLIP	1			400
80	20A-42510-03	GOVERNOR SPRING	1			400
310-480	20A-46502-00	SPEED CONT AY	1			400
485	20A-01111-00	FLANGE BOLT	2			400


This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or motor housing. The central part is a large, complex housing (10) with a flange (110) and a mounting flange (10). To the left, a motor or actuator assembly is shown, including a motor housing (62) and a mounting bracket (82). To the right, a circular flange (237) is shown. Various fasteners, including screws (80, 81, 82, 851, 852, 853, 854, 860, 861, 862) and pins (35, 40, 41, 60, 850), are shown in their respective positions. The diagram uses dashed lines to indicate the assembly path and alignment of the components.

5 COOLING STARTING

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK		FIG.
10	21D-51202-11	BLOWER HOUSING CP	1				500
20	X73-20058-20	LABEL (TRADE MARK)	1				500
40	20A-01114-00	FLANGE BOLT	4				500
60	20A-52711-01	BAFFLE 1 (CASE) CP	1				500
61	20A-52702-01	BAFFLE 2 (HEAD) CP	1				500
80	20A-01115-00	FLANGE BOLT	1				500
81	20A-01111-00	FLANGE BOLT	1				500
110	21D-54101-03	COOLING BLOWER	1				500
220	20A-01114-00	FLANGE BOLT	4				500

5 COOLING STARTING

FIG. 522




5 COOLING STARTING

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK		FIG.	
210	21D-50201-00	RECOIL STARTER AY	1				522	

6 FUEL LUBRICANT

FIG. 600




6 FUEL LUBRICANT

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	FIG.
10	20A-61101-11	FUEL TANK CP	1			600
20	X73-20057-60	LABEL (WARNING)	1			600
23	21D-09705-00	LABEL (EX21)	1			600
30	20A-04401-00	FUEL TANK CAP CP	1			600
40	20A-06401-00	FUEL FILTER	1			600
48	20A-06402-00	UNION	1			600
60	20A-01852-00	FLANGE NUT	2			600
63	20A-01116-00	FLANGE BOLT	1			600
70		FUEL PIPE CP	1			600
80	20A-08105-00	RUBBER PIPE	1			600
90	20A-05801-00	HOSE CLAMP	2			600
224	20A-43801-01	CHOKE LEVER CP	1			600

6 FUEL LUBRICANT

FIG. 640




6 FUEL LUBRICANT

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	FIG.
210	21D-62302-60	CARBURETOR AY	1			640

7 ELECTRIC DEVICE

FIG. 700



7 ELECTRIC DEVICE

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK		FIG.
10	20A-79231-01	FLYWHEEL CP	1				700
11	20A-79431-01	IGNITION COIL CP	1				700
50	20A-73101-01	WIRE 1 CP	1				700
60	20A-06601-00	SWITCH AY	1				700
70	20A-01403-00	TAPPING SCREW	2				700
100	20A-06701-00	SPARK PLUG	1				700
110	22E-06801-00	SPARK PLUG CAP	1				700