

SET

MODE

לקדוד השלט יש ללחוץ יחד על לחצני

עד שקוד השלט יהבהב, לשנות לקוד המבוקש על פי הרשום מטה,

באמצעות לחצני ה- (+) וה- (-) ולסיום ללחוץ על ON/OFF



01/02



01



01



03



04



05



06



07



08



09



10



11



12



13



14



15



16



17



18



19



19



19



19



20



21



22



23



24



25



26



27



28/29