

2KW □ □ □ □ □ □ □ □

□ □ : 10003-00365-00

□ □ : i2000

编制：

校对：

会签：

审核：

批准：

2KW □ □ □ □ □ □ □ □

E-01 整机爆炸图.....4

E-02 机器前壳总成爆炸图.....5

Before the machine shellexploded assembly diagram

E-03 机器后壳总成爆炸图.....6

After the machine shell exploded assembly diagram

E-04 逆变器进气盖板总成.....7

Inverter air intake cover assembly

E-05 消声器出气盖板总成.....8

Muffler outlet cover plate assembly

E-06 动力底板总成.....9

Power backplane assembly

E-07 燃油箱总成.....10

Fuel tank assembly


E-08 发动机总成.....12

Engine assembly

E-09 逆变器总成.....13

Inverter assembly


E-01 整机爆炸图



序号 NO.	零部件编码 Part NO.	零部件名称 Description			数量 QTY		
		中文	English	Price (USD)		I2000	N.W.(kg)/PC
1	33013-00038-00	机器前壳总成	Front cover assy			1	
2	33013-00055-00	消声器出气盖板总成	Muffler exhaust cover assy			1	
3	20260-02390-00	动力总成	Engine assy			1	

4	20130-00078-00	燃油箱总成	Fuel tank assy			1	
5	33013-00036-00	机器后壳总成	Rear cover assy			1	
6	33013-00043-00	逆变器进气盖板总成	Inverter air inlet cover assy			1	
7	20114-02522-00	控制面板总成	Control panel assy			1	
8	20136-00017-00	逆变器总成	Inverter assy			1	
9	33089-00004-00	动力底板总成	Bottom cover assy			1	


E-02 机器前壳总成爆炸图/Before the machine shell exploded assembly diagram



序号 NO.	零部件编码 Part NO.	零部件名称 Description			数量 QTY		
		中文	English	Price (USD)		i2000	N.W. (kg) /PC
1	33013-00046-09	前盖板	Front cover			1	
2	30117-00010-00	十字槽盘头自攻螺钉	Cross recessed pan head tapping screws			12	
3	33275-00003-00	缸头定位垫	Cylinder head fix washer			1	
4	33013-00038-00	机器前壳	Front panel			1	

5	30114-00031-00	内六角盘头螺栓 M6	Inside hexagonal bolt			3	
6	30111-00027-00	十字槽盘头螺钉 M6×12	Pan head screws with cross recess			1	
7	34024-00074-00	夹片螺母	Lock clip			4	
8	33014-00081-00	启动保护圈	Start protection			1	
9	70010-00079-00	启动拉手	Handle			1	
10	30111-00088-00	十字槽盘头螺钉 M5×14	Pan head screws with cross recess			2	
11	30125-00015-00	六角法兰面螺母 M3	Hexagon nuts with flange M3			2	
12	33593-00019-00	手柄挡块	Handle baffle			1	
13	30111-00071-00	十字槽盘头螺钉 M3×8	Pan head screws with cross recess			2	


E-03 机器后壳总成爆炸图/After the machine shell exploded assembly diagram



序号	零部件编码	零部件名称	Description	数量 QTY
----	-------	-------	-------------	--------

NO.	Part NO.	中文	English	Price (USD)		i2000	N.W. (kg) /PC
1	30111-00088-00	十字槽盘头螺钉 M5×14	Pan head screws with cross recess			2	
2	33015-00043-00	火花塞胶套/Φ42*Φ32.5*87.5	Rubber sleeve for spark plug			1	
3	33036-00053-00	油位口胶圈	Rubber gasket			1	
4	70009-00068-00	油位口透明块	Clear lens			1	
5	33275-00005-00	圆孔胶垫	Round hole rubber washer			1	
6	33275-00012-00	加油隔垫	Fuel insulator			1	
7	30111-00027-00	十字槽盘头螺钉 M6×12	Pan head screws with cross recess			1	
8	33275-00003-00	缸头定位垫	Cylinder head fix washer			1	
9	70009-00067-00	夹片螺母	Lock clip			4	
10	33013-00025-09	后盖板	Rear cover			1	
11	30111-00083-00	十字槽盘头螺钉 M5×14	Pan head screws with cross recess			2	
12	33015-00003-00	胶套	Round hole rubber washer			4	
13	33013-00036-00	机器后壳	Rear panel			1	
14	30114-00031-00	内六角盘头螺栓 M6	Inside hexagonal bolt			3	


E-04 逆变器进气盖板总成/Inverter air intake cover assembly



序号 NO.	零部件编码 Part NO.	零部件名称 Description			数量 QTY		
		中文	English	Price (USD)		i2000	N.W. (kg) /PC
1	31026-00065-00	□ □ □ □	Fuel Valve handle			1	
2	30111-00070-00	□ □ □ □ □ □ □ M4×12	Pan head screws with cross recess			1	
3	30117-00009-00	□ □ □ □ □ □ □ □ □ □ ST4×20	Cross recessed pan head tapping screws			6	
4	20114-00005-00	□ □ □ □ □ □	Control panel assy			1	

5	33013-00043-00	□ □ □ □ □ □ □	Inverter air inler cover			1	
6	30111-00088-00	□ □ □ □ □ □ □ M5×14	Pan head screws with cross recess			6	
7	30111-00027-00	□ □ □ □ □ □ □ M6X12	Pan head screws with cross recess			1	


E-05 消声器出气盖板总成/Muffler outlet cover plate assembly



序号 NO.	零部件编码 Part NO.	零部件名称 Description		数量 QTY			
		中文	English	Price (USD)		i2000	N.W. (kg) /PC
1	33013-00055-00	□ □ □ □ □ □ □	Muffler exhaust cover assy			1	
2	33015-00026-00	□ □ □ □	Alternator rubber sleeve			6	

3	30150-00026-00	□ □ □ □ □	Spring ring			1	
4	60007-00141-00	□ □ □	Filter screen			1	
5	30111-00088-00	□ □ □ □ □ □ □	Pan head screws with cross recess			1	


E-06 动力底板总成/Power backplane assembly



序号 NO.	零部件编码 Part NO.	零部件名称	Description		数量 QTY		
		中文	English	Price (USD)		i2000	N.W. (kg) /PC
1	30125-00002-00	□ □ □ □ □ □ M6	Hexagon nuts with flange M6			8	
2	33275-00018-00	□ □ □ □ □ □	Anti-vibration foot			4	
3	34032-00015-00	□ □ $\Phi 7 \times \Phi 10 \times 8.5\text{mm}$	Sleeve $\phi 7 \times 30 \times 8.5$			4	
4	33275-00006-00	□ □ □ □	Bottom washer of alternator			1	
5	30122-00002-00	□ □ □ M6	Square nut M6			6	

6	30101-00342-00	□ □ □ □ □ □ M6×20	Hexagon bolts with flange			4	
7	30136-00113-00	□ □ □	Flat washer			4	
8	34030-00026-00	□ □ □	Anti-vibration mounting			4	
9	33089-00004-00	□ □ □ □	Bottom cover			1	
10	70009-00067-00	夹片螺母	Lock clip			4	
11	33275-00019-00	□ □ □ □	Bottom washer of engine body			1	


E-07 燃油箱总成/Fuel tank assembly



序号 NO.	零部件编码 Part NO.	零部件名称 Description			数量 QTY		
		中文	English	Price (USD)		i2000	N.W. (kg) /PC
1	33015-00023-00	橡胶套	Rubber sleeve			2	
2	20130-00078-00(橡胶套、橡胶 套)	燃油箱总成	Fuel tank assy			1	

3	34037-00001-00	□ □ □ /Φ37.8*42.8*70/	Filter screen			1	
4	20131-00006-00	□ □ □ □	Fuel cap			1	
5	34037-00003-00	□ □ □ □ □ /Φ8.2*49、□ □ □ Φ3、□ □ □ Φ5	Filter screen			1	
6	34024-00003-00	□ □ /B12/□ □ /65MN	Lathedog			1	
7	34023-00009-00	□ □ □ / (Φ5*Φ10 , Φ7*Φ 12) *95	Fuel pipe			1	
8	34024-00024-00	□ □ /B9.5/□ □	Lathedog			1	
9	20133-00006-00	□ □ □ □	Fuel valve			1	
10	30101-00070-00	□ □ □ □ □ □ □ M6×12	Hexagon bolts with flange			2	


E-08 发动机总成/Engine assembly



序号 NO.	零部件编码 Part NO.	零部件名称 Description			数量 QTY		
		中文	English	Price (USD)		i2000	N.W. (kg) /PC
1	34006-00001-00	定位销/Φ8*Φ6.4*12/	Locating pin			2	
2	20005-00002-00	变频电机定子 /2.2KW/230V/	Motor stator			1	
3	30125-00034-00	六角法兰面螺母 (M12× P1.25/白锌)	Hexagon bolts with flange			1	
4	20006-00002-00	变频电机转子/Φ145*44.5/	Motor rotor			1	

5	33155-00066-00	冷却风扇	Cooling fan			1	
6	纯动力是 20260-01168-00;包 含定转子电机罩及 相应螺栓螺母动力 是 20260-02390-00	发动机总成	Engine			1	
7	30101-00530-00	六角法兰面螺栓 (M6×30 ×P1.0/白锌)	Hexagon bolts with flange			5	
8	33191-00130-00	电机罩	Alternator cover			1	
9	30139-00005-00	弹簧垫圈/Φ5/黑锌/	Spring washer				
10	30101-00276-00	六角法兰面螺栓 (M5×35 ×P0.8/白锌)	Hexagon bolts with flange			2	
11	30101-00588-00	六角法兰面螺栓 /M6*1/18/8.8 级/	Hexagon bolts with flange			2	

E-09 逆变器总成/Inverter assembly



序号 NO.	零部件编码 Part NO.	零部件名称 Description		数量 QTY			
		中文	English	Price (USD)		i2000	N.W. (kg) /PC
1	20030-00013-00	□ □ □ □ □ □ /□ □ 355	Choke cable			1	
2	30101-00070-00	□ □ □ □ □ □ □ (M6×12 ×P1.0/□ □)	Hexagon bolts with flange			8	
3	33015-00003-00	□ □ □ □ □	Round rubber sleeve			1	
4	33275-00005-00	□ □ □ □	Rubber sleeve			1	

5	20014-00067-00	□ □ □ □ □ □ □	Bracket			1	
6	20136-00017-00	□ □ □ □ □ /2KW/220V/50HZ/□ □ / □ □ □ □ /SC/	Inverter assy			1	