

PARTS LIST

MSD41 (3/4IN)

CONTENTS

1. POWER SPRAYER (CRANK CASE,INLET VALVE)	1 ~ 2
2. POWER SPRAYER (PRESSURE REGURATOR VALVE)	3 ~ 4
3. ACCESSORIES	5 ~ 6


2006.04



MARUYAMA


P/N. 522160

1. MSD41 (3/4IN) POWER SPRAYER (CRANK CASE,INLET VALVE)




Ref.No.	Parts No.	Parts Name	Q'ty	Remarks
1-1	354051	MSD41(3/4IN)	1	MSD41 Incl.5 P20
1-2	548895	Label	1	
1-3	547333	Crankcase	1	
1-4	547961	Oil Filler Cap, Ass'y	1	
1-5	014179	O-Ring	1	
1-6	044842	Plug	1	P20 7.0X19.07 #6204 2SF
1-7	014179	O-Ring	1	
1-8	545981	Crankshaft	1	
1-9	015710	Bearing	1	
1-10	547153	Bearing Case	1	
1-11	014488	Bearing	1	#6006 D30428 S100 M6X14
1-12	055337	Oil Seal	1	
1-13	014041	O-Ring	1	
1-14	547161	Bolt	3	
1-15	012385	Snap Ring	1	
1-16	092241	Oil Gauge Ass'y	1	Incl.17 25X34XT2 2SF38MM 9X22
1-17	044428	Packing	1	
1-18	547046	Connecting Rod	3	
1-19	016948	Piston Pin	3	
1-20	541809	Piston Rod	3	
1-21	020017	Washer	3	17X24XT1.2 S10.5247 10X19X5 Incl.26-31
1-22	025461	Oil Seal	3	
1-23	044869	Seal Retainer	3	
1-24	011402	Oil Wick	3	
1-25	639503	A Block	3	
1-26	014122	Inlet Valve Seat	3	6.1X20XT2.8 6X8.5X10.5 M6
1-27	116121	Piston Packing	3	
1-28	027348	Spacer	3	
1-29	119917	Piston Retainer	3	
1-30	015849	Spring Washer	3	
1-31	046365	Nut	3	M6 P21
1-32	545944	Manifold A	1	
1-33	540670	U Packing	3	
1-34	546860	Adapter	6	
1-35	015862	O-Ring	6	
1-36	023172	O-Ring	6	P22 25X28.5XL43
1-37	541811	Cylinder Pipe	3	
1-38	044881	Valve Seat	3	
1-39	544499	Manifold B	1	
1-40	044565	Valve Sack	3	
1-41	548608	Valve	3	16X1.5 0.6-15L M8X110X28
1-42	541062	Spring	3	
1-43	544090	Cap Screw	6	
1-44	548767	Label	1	
1-45	545158	Label	1	

2. MSD41 (3/4IN) POWER SPRAYER (PRESSURE REGURATOR VALVE)



Ref.No.	Parts No.	Parts Name	Q'ty	Remarks
2-1	546849	Pressure Regulator Valve, Ass'y	1	Incl.2-18
2-2	540936	Grip	1	
2-3	088913	Hexagon Socket Screw	1	M8X35
2-4	081039	Nut	1	M8
2-5	087483	Screw	2	M3XP0.5X5
2-6	088912	Hexagon Socket Screw	1	M4X6
2-7	106495	Guide	1	
2-8	106499	Washer	1	16X21X0.7T
2-9	541769	Spring Seat	1	15XT2.5
2-10	548819	Spring	1	3.0-31L
2-11	546500	Body	1	
2-12	107221	Spring	1	0.6-7L
2-13	106498	Valve Ball	1	5/32
2-14	543591	Piston Ass'y	1	
2-15	103306	Sleeve	1	
2-16	019261	O-Ring	1	P16
2-17	543507	Valve Seat	1	
2-18	019261	O-Ring	1	P16
2-19	542258	Cheese	1	R3/8XR3/8
2-20	541796	Ball Cock	1	R3/8XG1/4

3. MSD41 (3/4IN) ACCESSORIES



Ref.No.	Parts No.	Parts Name	Q'ty	Remarks
3-1	046271	Flange	1	
3-2	044843	Bolt	4	5/16-24UNFX20
3-3	012489	Washer	4	M8
3-4	015845	Spring Washer	4	M8
3-5	044683	Bolt	4	3/8-16UNCX35
3-6	012490	Washer	4	M10
3-7	012503	Spring Washer	4	M10
3-8	546043	Instruction Manual	1	MSD40




Maruyama U.S., Inc.
3570 Shelby Lane
Denton, TX 76207
940-383-7400 voice
940-383-7466 fax

www.maruyama-us.com

1 CRANK CASE GROUP


FIG. 100



1 CRANK CASE GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.
10	20A-10103-11	CRANK CASE CP	1		曲轴箱组件		100
	20A-10103-01	CRANK CASE CP	1		曲轴箱组件		100
	20A-10103-02	CRANK CASE UN			曲轴箱		
26	20A-16010-01	STEM SEAL	1		气门油封		100
30	20A-04801-00	OIL SEAL	1		油封		100
40	20A-06101-00	BALL BEARING	1		轴承		100
50	20A-15011-03	PIPE KNOCK	2		定位销		100
60	20A-01611-00	STUD	2		双头螺栓		100
70	20A-01601-00	STUD	2		双头螺栓		100
75	20A-04802-00	OIL SEAL	1		油封		100
80	20A-04101-00	PLUG	2		放油螺栓		100
90	20A-02202-00	GASKET	2		垫片		100
210	20A-11002-01	MAINBEARING COVER CP	1		曲轴箱盖组件		100
220	20A-04803-00	OIL SEAL	1		油封		100
230	20A-06102-00	BALL BEARING	1		滚珠轴承		100
250	20A-45004-01	GOVERNOR GEAR CP	1		调速齿轮		100
260	20A-41901-03	GOVERNOR SLEEVE	1		调速套筒		100
285	20A-63601-00	OIL GAUGE AY	2		油标尺		100
300	20A-01101-00	FLANGE BOLT	6		法兰螺栓		100
610	20A-13001-01	CYLINDER HEAD CP	1		气缸头组件		100
	20A1300102	CYLINDER HEAD	1				
620	20A-15001-03	GASKET (HEAD)	1		气缸头垫片		100
630	20A-01102-00	FLANGE BOLT	4		法兰螺栓		100
631	20A-01103-00	FLANGE BOLT	1		法兰螺栓		100
680	20A-15505-01	ROCKER COVER CP	1		缸盖罩		100
690	20A-16001-13	GASKET (ROCKER COVER)	1		垫片(缸盖罩)		100
700	20A-15011-03	PIPE KNOCK	2		定位销		100
710	20A-01111-00	FLANGE BOLT	4		法兰螺栓		100

FIG. 200




2 CRANKSHAFT, PISTON GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
10	20A-21201-11	CRANK SHAFT CP	1		曲轴		200	
50	20A-01853-00	FLANGE NUT	1		法兰螺母		200	
70	20A-03601-00	WOODRUFF KEY	1		半圆键		200	
80	20A-03612-00	KEY	1		曲轴平键		200	
310	20A-22501-10	CONNECTING ROD AY	1		连杆总成		200	
350	20A-23301-03	PISTON PIN	1		活塞销		200	
360	20A-23401-03	PISTON	1		活塞		200	
375	20A-23611-03	TOP RING	1		一环		200	
376	20A-23711-03	SECOND RING	1		二环		200	
377	20A-23931-01	OIL RING CP	1		油环组合		200	
380	20A-03201-00	CLIP	2		活塞销挡圈		200	

3 INTAKE, EXHAUST GROUP

FIG. 300



3 INTAKE, EXHAUST GROUP


REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.
10	20A-31601-01	CAM SHAFT CP	1		凸轮轴		300
23	20A-35101-01	PIN(CAM SHAFT)CP	1		销轴(凸轮轴)		300
27	20A-02801-00	O RING	1		O型圈		300
60	20A-33601-03	VALVE SPRING	2		气门弹簧		300
70	20A-33701-03	SPRING RETAINER	2		气门弹簧盘		300
80	20A-33401-03	INTAKE VALVE	1		进气门		300
90	20A-33501-03	EXHAUST VALVE	1		排气门		300
95	20A-33801-03	COLLET-VALVE	4		气门卡锁		300
150	20A-35601-01	TIMING CHAIN CP	1		正时链条		300
160	20A-36911-03	TENTIONER	1		张紧器		300
163	20A-37101-03	SPRING(TENTIONER)	1		弹簧(张紧器)		300
166	20A-36902-03	PIN(TENTIONER)	1		销(张紧器)		300
170	20A-36913-03	CHAIN GUIDE	1		链条导向板		300
200	20A-35004-01	PIN(ROCKER) CP	1		摇臂销		300
202	20A-03211-00	CLIP	1		卡簧		300
220	20A-36201-00	ROCKER ARM(IN) AY	1		摇臂(进气)		300
225	20A-36202-00	ROCKER ARM(EX) AY	1		摇臂(排气)		300
290	20A-01111-00	FLANGE BOLT	1		法兰螺栓		300

3 INTAKE, EXHAUST GROUP


REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
310	20A-30101-11	MUFFLER CP	1		消声器		300	
320	20A-34201-10	MUFFLER COVER CP	1		消声器罩		300	
340	20A-35201-03	GASKET (MUFFLER)	1		垫片 (消声器)		300	
350	20A-01851-20	FLANGE NUT	2		法兰螺母		300	
360	20A-01201-00	TAPPING BOLT	2		自攻螺栓		300	
361	20A-01112-00	FLANGE BOLT	1		法兰螺栓		300	
365	20A-01104-00	FLANGE BOLT	1		法兰螺栓		300	
367	20A-02101-00	WASHER	1		垫圈		300	
540	20A-32902-01	INSULATOR CP	1		绝缘隔热板		300	
550	20A-35903-03	GASKET 2 (INSULATOR)	1		垫片 (绝缘隔热板)		300	
560	20A-35902-03	GASKET 1 (INSULATOR)	1		垫片 (绝缘隔热板)		300	
570	20A-01852-00	FLANGE NUT	2		法兰螺母		300	
580	20A-01113-00	FLANGE BOLT	1		法兰螺栓		300	
850	20A-08111-00	RUBBER PIPE	1		橡胶管		300	

FIG. 325

DUAL ELEMENT



URETHANE FOAM




3 INTAKE, EXHAUST GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
						部品番号		
510	20A-32633-00	AIR CLEANER AY	1		空滤总成	DUAL	325	
520	20A-32636-00	ELEMENT AY	1		滤芯		325	
530	20A-32614-03	PACKING	1		空滤器垫片		325	
910	20A-32615-03	LABEL	1		标签（阻风门）		325	

4 GOVERNOR OPERATION GROUP


FIG. 400



4 GOVERNOR OPERATION GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
13	20A-42301-00	GOVERNOR LEVER AY	1		摆动杆		400	
20	20A-42201-03	GOVERNOR SHAFT	1		调速器推杆		400	
30	20A-42701-01	GOVERNOR ROD CP	1		调速器拉杆		400	
40	20A-42801-03	ROD SPRING	1		拉杆拉簧		400	
50	20A-03211-00	CLIP	1		卡簧		400	
80	20A-42510-03	GOVERNOR SPRING	1		调速弹簧		400	
310-480	20A-46502-00	SPEED CONT AY	1		调速机构部件		400	
485	20A-01111-00	FLANGE BOLT	2		法兰螺栓		400	


FIG. 500



5 COOLING, STARTING GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
10	20A-51203-11	BLOWER HOUSING CP	1		导风罩		500	
20		LABEL (TRADE MARK)	1		标签 (商标)		500	
40	20A-01114-00	FLANGE BOLT	4		法兰螺栓		500	
60	20A-52711-01	BAFFLE 1 (CASE) CP	1		箱体导风板		500	
61	20A-52702-01	BAFFLE 2 (HEAD) CP	1		缸头导风板		500	
80	20A-01115-00	FLANGE BOLT	1		法兰螺栓		500	
81	20A-01111-00	FLANGE BOLT	1		法兰螺栓		500	
110	20A-54101-13	COOLING BLOWER	1		风扇		500	
220	20A-01114-00	FLANGE BOLT	4		法兰螺栓		500	

FIG. 522




5 COOLING, STARTING GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
210	20A-50201-30	RECOIL STARTER AY	1		起动机部件		522	

6 FUEL, LUBRICANT GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
10	20A-61101-11	FUEL TANK CP	1		燃油箱		600	
20	X73-20057-60	LABEL(WARNING)	1		标签（警示标签）		600	
23	20A-09709-00	LABEL(EX17)	1		型号标签（EX17）		600	
30	20A-04401-00	FUEL TANK CAP CP	1		油箱盖		600	
40	20A-06401-00	FUEL FILTER	1		油箱滤网		600	
48	20A-06402-00	UNION	1		油嘴组		600	
60	20A-01852-00	FLANGE NUT	2		法兰螺母		600	
63	20A-01116-00	FLANGE BOLT	1		法兰螺栓		600	
70	20A-62605-01	FUEL PIPE CP	1		燃油管		600	
80	20A-08104-00	RUBBER PIPE	1		橡胶管		600	
90	20A-05804-00	HOSE CLAMP	2		管夹		600	
224	20A-43801-01	CHOKE LEVER CP	1		阻风门手柄		600	


FIG. 640



6 FUEL, LUBRICANT GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
210	20A-62302-60	CARBURETOR AY	1		化油器总成		640	

FIG. 700



7 ELECTRIC DEVICE GROUP

REF.	PART NUMBER	PART NAME	QTY	Order QTY	REMARK	REMARK	FIG.	
10	20A-79231-01	FLYWHEEL CP	1		飞轮		700	
11	20A-79431-01	IGNITION COIL CP	1		点火线圈		700	
30	20A-01302-00	BOLT AND WASHER AY	2		螺栓组合件		700	
50	20A-73101-01	WIRE 1 CP	1		熄火线1		700	
60	20A-06601-00	SWITCH AY	1		停止开关			
70	20A-01403-00	TAPPING SCREW	2		螺丝			
100	20A-06701-00	SPARK PLUG	1		火花塞		700	
110	22E-06801-00	SPARK PLUG CAP	1		火花塞帽		700	