Parts List

| 1 | Main Frame | | 1 |
|----|------------------------------|-----|---|
| 2 | Right Leg | | 2 |
| 3 | Left Leg | | 2 |
| 4 | Leg Panel | | 2 |
| 5 | Goal With Wire | | 2 |
| 6 | Electronic Scorer | | 1 |
| 7 | Leg Leveler | | 4 |
| 8 | Pusher | | 2 |
| 9 | Felt Pad | | 2 |
| 10 | Round Puck | | 2 |
| 11 | Motor (Pre-installed) | | 1 |
| 12 | Apron Corner (Pre-installed) | | 4 |
| 13 | "AAA" Battery (Not included) | - + | 2 |

Hardware


| 14 | 1/4" x 1-1/8" Leg Bolt | 12 |
|----|------------------------------|----|
| 15 | 1/4" xφ15x1.2 Leg Washer | 12 |
| 16 | 4 x 12mm Screw | 18 |
| 17 | 3 x 15mm Screw | 2 |
| 18 | 1/4" T - Nut (Pre-installed) | 12 |
| 19 | 5/16"T - Nut (Pre-installed) | 4 |
| 20 | Allen Key | 1 |

Assembly Instructions

Step 1:

- Find a clean, level place to begin the assembly of your Air Hockey Table. The table will be assembled upside down and then turned over on its legs once the assembly completed. This game table is heavy, and turning it over will require at least two adults.
- Remove all the parts from the box and verify that you have all of the listed parts as shown on the parts list page. Carefully cut or tear the four corners of the box so that the bottom of the box can be used as your work surface.
- 3. Place the Main Frame (#1) face down on a clean and flat surface. Attach the Right Legs (#2) and Left Legs (#3) to the Main Frame using three Leg Bolts (#14) and three Leg Washers (#15) per Leg.
- 4. Screw the Leg Levelers (#7) into the bottom of each leg.






Step 2:

5. Attach the Leg Panels (#4) to the Legs using six Screws (#16) per Leg Panel.






Assembly Instructions

Step 3:

- Thread the wires from Goal Boxes (#5) through the openings of the end aprons and supports of the playfield to the opening of side apron and use Velcro Straps to fix Goal Wires.
- 7. Lift the table assembly from the floor with two strong adults. Turn the table over and set it down on the legs. Go back and make sure that all connections are tight.
- 8. Attach the Goals (#5) to each end apron of the Main Frame (#1) using three Screws (#16).
- 9. Attach the Electronic Scorer (#6) to the side apron in the pre-drilled holes using two Screws (#17). Insert the Goal Wire (#5) into the Electronic Scorer (#6).

CAUTION:Two strong adults are required to turn the table over as shown.

- 1. Lift the table off the ground.
- 2. Turn the table over.
- 3. Place it on all four feet at the same time on the ground



Step 4:

10. Tear off the backside paper of the Felt Pads (#9) and stick them at the bottom of the Pushers (#8).



