



PARTS LIST



Stump Grinder


REF. NO.	PART DESCRIPTION	REF. NO.	PART DESCRIPTION
1	frame	32	inner brake clamp plate
2	blade cover	33	engine
3	bearing	34	wheel flange
4	short axle sleeve	35	wheel (right)
5	blade adapter	36	wheel (left)
6	straight blade	37	throttle
7	right blade	38	emergency stop switch
8	left blade	39	emergency stall switch
9	blade clamp plate	40	pin
10	long axle sleeve	A1	M12 self-lock nut
11	belt (inner) cover	A2	M10 self-lock nut
12	belt wheel	A3	M12*45 inner hex bolt(8.8)
13	belt cover fitting rod	A4	M12*30 inner hex bolt
14	V-belt	A5	φ 12*φ 24*T1.5 flat gasket
15	belt (outer) cover	A6	M8*20 hex bolt
16	clutch	A7	M10*20 hex bolt
17	drum brake	A8	M10*45 hex bolt(engine)
18	handle connector	A9	M10*80 hex bolt
19	cable	A10	φ 8*φ 16 flat gasket
20	brake lever top cover	A11	M8*20 hex bolt
21	brake cable fitting screw rod	A12	M10*45 inner hex bolt(8.8)
22	brake cable fitting screw nut	A13	M8*20 inner hex bolt
23	brake clamp plate(outer)	A14	M14*1.5 self-lock nut
24	brake pin	A15	φ 14*φ 28*T2 flat gasket
25	brake connect plate	A16	M8*25 hex bolt
26	inner spacer	A17	M12*25 inner hex bolt
27	brake handle	A18	M12*65 inner hex bolt
28	outer sleeve	A19	M8*45 inner hex bolt
29	brake adjust screw rod	A20	φ 7 jump ring
30	brake rod cover	A21	M8 self-lock nut
31	handrail		

BLADE ASSEMBLY




REF. NO.	DESCRIPTION
3	Bearing
A1	M12 self-lock nut
4	Short axle sleeve
5	Blade adapter
6	Straight blade
7	Right blade
8	Left blade
9	Blade clamp plate
10	Long axle sleeve
A2	M10 self-lock nut
A12	M10*45 inner hex bolt(8.8)

HANDRAIL ASSEMBLY




REF.NO.	DESCRIPTION	REF.NO.	DESCRIPTION
18	Handle connector	40	pin
31	handrail	A17	M12*25 inner hex bolt
37	Throttle	A18	M12*65 inner hex bolt
38	Emergency stop switch		
39	Emergency stall switch		

BRAKE ASSEMBLY




REF.NO.	DESCRIPTION	REF.NO.	DESCRIPTION
19	Cable	27	Brake handle
20	Brake lever top cover	28	Outer sleeve
21	Brake cable fitting screw rod	29	Brake adjust screw rod
22	Brake cable fitting screw nut	30	Brake rod cover
23	Brake clamp plate(outer)	32	Inner brake clamp plate
24	Brake pin	A19	M8*45 inner hex bolt
25	Brake connect plate	A20	φ 7 jump ring
26	Inner spacer	A21	M8 self-lock nut

DRIVE SYSTEM ASSEMBLY



REF.NO.	DESCRIPTION	REF.NO.	DESCRIPTION
11	Belt (inner) cover	16	Brake assembly
12	Belt wheel	A7	M10*20 hex bolt
13	Belt cover fitting rod	A13	M8*20 inner hex bolt
14	V-belt	A16	M8*25 hex bolt
15	Belt (outer) cover	A21	M8 self-lock nut

ENGINE ASSEMBLY



Stump Grinder

REF.NO.	DESCRIPTION
1	frame
2	blade cover
17	drum brake
33	engine
34	wheel flange
35	wheel (right)
36	wheel (left)
A1	M12 self-lock nut
A2	M10 self-lock nut
A3	M12*45 inner hex bolt (8.8)
A4	M12*30 inner hex bolt
A5	Φ 12*Φ 24*T1.5 flat gasket
A6	M8*20 hex bolt
A7	M10*20 hex bolt
A8	M10*45 hex bolt (engine)
A9	M10*80 hex bolt
A10	Φ 8*Φ 16 flat gasket
A11	M8*20 hex bolt
A14	M14*1.5 self-lock nut
A15	Φ 14*Φ 28*T2 flat gasket