



EXTERNAL RECEIVER

BS-REC2(Ver2.3k) -2

SPECIFICATIONS:

1. Power supply:12V/24V AC/DC
2. Frequency :433.92MHz
3. Maximum storage:400 codes
4. 2 channel



※ When the input power is 24V, Please Jump on 24V (factory setting 12V) .

PROGRAMMING:

1. Learning transmitter's codes:

Press "learn1" or "learn2" for 1 second, the "learn_led" light, then, press the button which you choose on the transmitter till the "learn_led" flash and go out, the transmitter's code has been stored.

- Repeat the above steps for other transmitters.

2. Erasing transmitter's codes:

Press "learn1" and "learn2" and hold on to make the "learn_led" light till go out, all codes of transmitters which had been stored are erased.